

Parts List for J-337 Type 1

Item Number	Part Number	Description	Qty Required
1	680967	ARMATURE 115V	1
1	000000-00	No Longer Available	1
1	000000-00	No Longer Available	1
1	696169	AIR BAFFLE	1
2	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
3	000000-00	No Longer Available	2
3	000000-00	No Longer Available	2
4	5140112-36	SWITCH KIT	1
5	A11126	CORDSET	1
11	855284	BEARING	3
11	859293	BEARING	3
12	803856	BEARING	3
13	804211	BEARING,NEEDLE	3
15	839837	NEEDLE BEARING	1
23	848537	SEAL	1
31	D688257	PINION	1
31	878571	GEAR	1
37	848530	BELT	1
37	695738	DRIVE PULLEY	1
37	899259	DRIVE PULLEY	1
40	698038	SHAFT	1
40	849155	PULLEY SHAFT	1
51	000000-00	No Longer Available	1
53	848523	COVER	1
54	875923	BELT COVER	1
57	696098	HANDLE SET	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-337 Type 1

Item Number	Part Number	Description	Qty Required
59	000000-00	No Longer Available	1
59	849161	HSG	1
64	848513	FRAME BAR	1
65	698041	DRIVE PULLEY	1
65	900527	DRIVEN PULLEY	1
66	848519	ARM	1
90	000000-00	No Longer Available	1
93	897160	SCREW	10
100	000000-00	No Longer Available	1
101	848532	SPRING	10
102	000000-00	No Longer Available	1
103	848541	SUPPORT	1
104	852003	GASKET	1
105	852004	GASKET	1
106	852005	GASKET	1
107	849808	SCREW	10
108	859359	WASHER	10
109	848508	WASHER	10
110	801821	WASHER	10
111	802943	NUT	10
112	847994	SCREW	10
113	847564	SNAP RING	3
114	000000-00	No Longer Available	10
115	802764	SCREW	10
116	848524	GASKET	1
117	848512	SPRING	10
118	903693	NUT	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-337 Type 1

Item Number	Part Number	Description	Qty Required
120	801374	SCREW	10
121	849192	NUT	10
122	848551	WASHER	10
124	000000-00	No Longer Available	1
125	848514	SPRING	10
126	856481	SCREW	10
128	848565	SCREW	10
129	A03070	SS/A HANDLE SET	1
130	802995	WASHER	10
131	893792	SCREW	10
133	886538	SCREW	10
134	848547	COVER	1
135	903400	CORK & SHOE ASSY.	1
136	684987	CLAMP	1
137	883485	SCREW	10
138	802648	WASHER	10
139	869687	NUT	10
140	848148	SCREW	10
141	802845	COTTER PIN	1
142	852067	DUST SCOOP	1
143	849819	SCREW	10
144	877817	SCREW	10
145	893792	SCREW	10
146	878057	SCREW	10
147	847048	SCREW	10
148	875322	SCREW	1
149	848534	BAFFLE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for J-337 Type 1

Item Number	Part Number	Description	Qty Required
150	000000-00	No Longer Available	1
151	878813	SCREW	10
153	000000-00	No Longer Available	1
154	000000-00	No Longer Available	10
156	802764	SCREW	10
158	853480	SCREW	10
159	848557	CLIP-BRUSH HOLDER	1
162	000000-00	No Longer Available	1
164	844107	SCREW	10
169	849314	TERM	1
170	850218	WASHER	10
173	848148	SCREW	10
174	696039	LOCATOR	1
175	801530	WASHER	10
177	810523	WASHER	10
179	682063	CONNECTOR VS	1
180	823374	WASHER	10
181	000000-00	No Longer Available	1
182	810238	FAN	1
183	801945	TUBE GREASE	1
183	801946	LUBE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.