
# JET JLH-25-5 | Stock 181205

## Diagram A - JLH-25 Compact Lever Hoist

Lever Hoist | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-25-5 | Stock 181205

## Parts List A - JLH-25 Compact Lever Hoist

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | JT9-JLH25-1G | Top Hook Assembly | | 1 |
| | ** | Top Hook | | 1 |
| | ** | Safety Latch Kit | | 1 |
| | ** | Top Hook Holder | | 1 |
| 2 | JT9-JLH25-2 | Safety Latch Kit | | 2 |
| | ** | Safety Latch | | 2 |
| | ** | Double Spring | | 2 |
| | ** | Socket Cap Screw | | 2 |
| | ** | Lock Nut | | 2 |
| 3 | JT9-JLH25-3 | Top Hook Shaft | | 1 |
| 4 | JT9-JLH25-4G | Bottom Hook Assembly | | 1 |
| | ** | Bottom Hook | | 1 |
| | ** | Bottom Hook Holder | | 1 |
| | ** | Safety Latch Kit | | 1 |
| 5 | ** | Chain pin and Lock Nut | M4 | 1 |
| 7 | ** | Gear Cover Set | | 1 |
| 8 | JT9-JLH25-8 | Reinforced Plate | | 1 |
| 9 | JT9-JLH25-9 | Load Gear | | 2 |
| 10 | JT9-JLH25-10 | Pinion Shaft | | 1 |
| 11 | JT9-JLH25-11 | Gear Side Plate | | 1 |
| 12 | JT9-JLH25-12 | Chain Stripper | | 1 |
| 13 | JT9-JLH25-13 | Stay Bolt | | 2 |
| 16 | JT9-JLH25-16N | Load Sprocket | | 1 |
| 17 | JT9-JLH25-17N | Load Gear | | 1 |
| 18 | JT9-JLH25-18 | Chain Guide | | 2 |
| 19 | JT9-JLH25-19 | Lever Side Plate Assembly | | 1 |
| | ** | Lever Side Plate | | 1 |
| | ** | Pawl Pin | | 2 |
| 20 | JT9-JLH25-20 | Pawl Spring (0.25,0.5 ton) | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-25-5 | Stock 181205

## Parts List A - JLH-25 Compact Lever Hoist (continued)

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 21 | JT9-JLH25-21 | Pawl (0.25,0.5 ton) | | 2 |
| 22 | JT9-JLH25-22 | Snap Ring (0.25,0.5 ton) | 6mm | 2 |
| 23 | JT9-JLH25-23 | Brake Seat | | 1 |
| 24 | JT9-JLH25-24N | Fused Brake Disc | | 1 |
| 26 | JT9-JLH25-26 | Twisting Spring | | 1 |
| 27 | JT9-JLH25-27 | Brake Plate | | 1 |
| 28 | JT9-JLH25-28 | Bushing | | 1 |
| 29 | JT9-JLH25-29 | Stop Knob | | 1 |
| 30 | JT9-JLH25-30G | Brake Cover | | 1 |
| 31 | JT9-JLH25-31G | Socket Head Screw and Spring Washer | M5x40 and 5mm | 3 |
| 33 | JT9-JLH25-33 | Snap Ring | 9mm | 1 |
| 34 | JT9-JLH25-34 | Change Over Gear | | 1 |
| 35 | JT9-JLH25-35 | Lever Handle Assembly | | 1 |
| | ** | Lever Handle | | 1 |
| | ** | Selector Level | | 1 |
| | ** | Change Over Pawl | | 1 |
| | ** | Snap Ring | 6mm | 1 |
| | ** | Roller | Ø5mm | 1 |
| | ** | Change Over Spring | | 1 |
| 36 | JT9-JLH25-36 | Snap Ring | 22mm | 1 |
| 37 | JT9-JLH25-37G | Handwheel | | 1 |
| 38 | JT9-JLH25-38 | Snap Ring | 7mm | 1 |
| 40 | JT9-JLH25-40 | Rubber Grip | | 1 |
| 41 | JT9-JLH25-41 | Bolt and Locking Nut (0.25,0.5 ton) | M3.5 | 1 |
| 48 | JT9-JLH25-48 | Load Chain - specify length | 3.2x9 mm | 1 |
| 49 | JT9-JLH25-49 | End Chain Ring | | 1 |
| | JT9-JLH25-50 | Carry Pouch for JLH-25 (not shown) | 95x70x180mm | 1 |
| | JT9-LM000040 | Name Plate JLH-25 (not shown) | | 1 |
| | JT9-JLH25-BSK | Brake Service Kit, JLH-25 (includes #23,24,27) | | 1 |

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as

Note: All parts mentioned as assembly are sold as an assembly only. When ordering replacement chain (#48), specify

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com