
# JET JLH-300-20PSH | Stock 376903

## Diagram A - JLH-300 Lever Hoist

Lever Hoist | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-300-20PSH | Stock 376903

## Parts List A - JLH-300 Lever Hoist

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | JT9-JLH320-1G | Gear Case Assembly (3, 6, 9 Ton) | | 1 |
| | | Gear Case | | 1 |
| | | Bushing | | 3 |
| | | Cover Plate | | 1 |
| 2 | CM9-JLH320-2 | Spur Gear Assembly (3, 6, 9 Ton) | | 2 |
| | | Spur Gear | | 2 |
| | | Pinion Gear | | 2 |
| 3-2 | JT9-JLH320-3-2 | Driving Shaft (3, 6, 9 Ton) | | 1 |
| 4 | JT9-JLH320-4 | Load Gear (3, 6, 9 Ton) | | 1 |
| 5 | JT9-JLH320-5 | Gear Side Plate Assembly (3, 6, 9 Ton) | | 1 |
| | | Gear Side Plate | | 1 |
| | | Bushing | | 2 |
| 6 | JT9-JLH320-6 | Caged Roller Bearings (3, 6, 9 Ton) | Ø40xØ50x15mm | 2 |
| 7 | JT9-JLH320-7 | Load Sheave (3, 6, 9 Ton) | | 1 |
| 8 | JT9-JLH320-8 | Guide Roller (3, 6, 9 Ton) | | 2 |
| 9 | JT9-JLH320-9 | Stripper (3, 6, 9 Ton) | | 1 |
| 10 | JT9-JLH320-10 | Lever Side Plate Assembly (3, 6, 9 Ton) | | 1 |
| | | Lever Side Plate | | 1 |
| | | Stay Bolt | | 4 |
| | | Pawl Pin | | 2 |
| 11 | JT9-JLH320-11 | Pawl Spring (3, 6, 9 Ton) | | 2 |
| 12 | JT9-JLH320-12 | Pawl (3, 6, 9 Ton) | | 2 |
| 13 | JT9-JLH320-13 | Snap Ring (3, 6, 9 Ton) | Ø 10mm | 2 |
| 14 | JT9-JLH320-14 | Disc Hub (3, 6, 9 Ton) | | 1 |
| 15 | JT9-JLH320-15 | Ratchet Disc (3, 6, 9 Ton) | | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-300-20PSH | Stock 376903

## Parts List A - JLH-300 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 16-1 | JT9-JLH320-16-1 | Brake Cover Assembly (3, 6, 9 Ton) | | 1 |
| | | Brake Cover | | 1 |
| | | Handle Case | | 1 |
| | | Bushing | | 1 |
| | | Thread Housing | | 1 |
| 17-1 | JT9-JLH320-17G | Acorn Nut (3, 6, 9 Ton) | M8 | 2 |
| 17A | JT9-JLH320-17AG | Lock Washer (3, 6, 9 Ton) | 8mm | 2 |
| 18 | JT9-JLH80-18G | Lock Washer (0.75 to 9 Ton) | 8mm | 8 |
| 19 | JT9-JLH80-19G | Acorn Nut (0.75 to 9 Ton) | M8 | 8 |
| 20-2 | JT9-JLH320-20-2 | Change Over Gear (3, 6, 9 Ton) | | 1 |
| 20-2L | JT9-JLH320-20L-2 | Overload Limiter Assembly | | 1 |
| | | Overload Limiting Plate | | 1 |
| | | Change Over Gear | | 1 |
| | | Pressure Plate | | 1 |
| | | Dish Spring | | 1 |
| | | Washer | | 1 |
| | | Lock Washer | | 1 |
| | | Round Nut | M30x1 | 1 |
| 21 | JT9-JLH320-21 | Change Over Pawl (3, 6, 9 Ton) | | 1 |
| 22 | JT9-JLH320-22 | Spring Shaft (3, 6, 9 Ton) | | 1 |
| 23 | JT9-JLH320-23 | Spring (3, 6, 9 Ton) | | 1 |
| 24-1 | JT9-JLH320-24-1 | Lever Handle Assembly (3, 6, 9 Ton) | | 1 |
| | | Lever Handle | | 1 |
| | | Selector Lever | | 1 |
| | | Change Over Shaft | | 1 |
| | | Bolt | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-300-20PSH | Stock 376903

## Parts List A - JLH-300 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| | | Spring Seat | | 1 |
| | | Bushing | | 1 |
| 24A-1 | JT9-JLH320-24A-1 | Rubber Grip (3, 6, 9 Ton) | | 1 |
| 25 | JT1-409 | Socket Head Cap Screw (3, 6, 9 Ton) | M8 x 16 | 1 |
| 25A | JT9-JLH320-25AG | Lock Washer (2.5, 3, 6, 9 Ton) | 8mm | 1 |
| 26-2 | JT9-JLH320-26-2A | Stop Knob (3, 6, 9 Ton) | | 1 |
| 27-1 | JT9-JLH320-27-1 | Twisting Spring (3, 6, 9 Ton) | | 1 |
| 28-2 | JT9-JLH320-28-2 | Hand Wheel Assembly (3, 6, 9 Ton) | | 1 |
| | | Hand Wheel | | 1 |
| | | Steel Ball Spring | | 2 |
| | | Steel Ball | | 2 |
| 29-1 | JT9-JLH320-29-1 | Hand Wheel Cap (3, 6, 9 Ton) | | 1 |
| 30-1 | JT9-JLH320-30-1 | Hand Wheel Base Assembly (3, 6, 9 Ton) | | 1 |
| | | Hand Wheel Base | | 1 |
| | | Bushing | | 2 |
| 31-1 | JT9-F001755 | Lock Nut | M10 | 1 |
| 32-1 | JT9-JLH320-32-1 | Steel Cable Ring (3 to 9 Ton) | | 1 |
| 33 | JT9-JLH80-33 | Rivet (0.75 to 9 Ton) | 3 x 6mm | 4 |
| 34-1 | JT9-LM000195 | Name Plate JLH-300 | | 1 |
| 35 | JT9-F001755 | Lock Nut | M10 | 1 |
| 36 | JT9-JLH320-36 | Bottom Hook Shaft | | 1 |
| 37 | JT9-JLH320-37-1 | Safety Latch Kit | | 2 |
| | | Safety Latch | | 2 |
| | | Double Spring | | 2 |
| | | Socket Cap Screw | M6 x 33 | 2 |
| | | Lock Nut | M6 | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET JLH-300-20PSH | Stock 376903

## Parts List A - JLH-300 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 38-1 | JT9-JLH320-38-1 | Bottom Hook Assembly (incls. 35 & 36) (standard hook) | | 1 |
| 38-1 | JT9-JLH320-38PH-1 | Bottom Point Hook Assembly (incls. 35 & 36) (ship yard hook) | | 1 |
| | | Bottom Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Cap Screw | M6 x 33 | 1 |
| | | Lock Nut | M6 | 1 |
| | | Bottom Hook Holder | | 2 |
| | | Rivet | 7 x 25mm | 4 |
| 39 | JT9-JLH320-39 | Top Hook Shaft (3, 6, 9 Ton) | | 1 |
| 40 | JT9-JLH320-40-1 | Top Hook Assembly (standard hook) | | 1 |
| 40 | JT9-JLH320-40PH-1 | Top Point Hook Assembly (ship yard hook) | | 1 |
| | | Top Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Cap Screw | M6 x 33 | 1 |
| | | Lock Nut | M6 | 1 |
| | | Top Hook Holder | | 2 |
| | | Rivet | 7 x 25mm | 2 |
| 41 | JT9-JLH320-41 | Chain Stop (3, 6, 9 Ton) | | 1 |
| 42 | JT9-JLH320-42 | Drive Shaft Washer (3, 6, 9 Ton) | | 1 |
| 49 | JT9-JLH320-49 | Load Chain (3, 6, 9 Ton) - specify length | #100,Ø10 x 28mm | 1 |
| 50 | JT9-JLH320-50 | Rubber Grip Fastening (3, 6, 9 Ton) | | 1 |
| 50A | JT9-JLH320-50A | Fastening Screw (3, 6, 9 Ton) | | 1 |
| | JT9-JLH-7040WL | Warning Label (not shown) | 70x40mm | 1 |
| 52 | JT9-L100-WT | Warning Tag | | 1 |

Note: Top and bottom hooks are sold as an assembly only. Both standard and point hooks are available for the 3 ton

When ordering replacement chain (#49), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com