
JET JLH-600WO-5 | Stock 376600

Diagram A - JLH-600 Lever Hoist

Lever Hoist | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET JLH-600WO-5 | Stock 376600

Parts List A - JLH-600 Lever Hoist

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	JT9-JLH320-1G	Gear Case Assembly (3, 6, 9 Ton)		1
		Gear Case		1
		Bushing		3
		Cover Plate		1
2	CM9-JLH320-2	Spur Gear Assembly (3, 6, 9 Ton)		2
		Spur Gear		2
		Pinion Gear		2
3-2	JT9-JLH320-3-2	Driving Shaft (3, 6, 9 Ton)		1
4	JT9-JLH320-4	Load Gear (3, 6, 9 Ton)		1
5	JT9-JLH320-5	Gear Side Plate Assembly (3, 6, 9 Ton)		1
		Gear Side Plate		1
		Bushing		2
6	JT9-JLH320-6	Caged Roller Bearings (3, 6, 9 Ton)	Ø40xØ50x15mm	2
7	JT9-JLH320-7	Load Sheave (3, 6, 9 Ton)		1
8	JT9-JLH320-8	Guide Roller (3, 6, 9 Ton)		2
9	JT9-JLH320-9	Stripper (3, 6, 9 Ton)		1
10	JT9-JLH320-10	Lever Side Plate Assembly (3, 6, 9 Ton)		1
		Lever Side Plate		1
		Stay Bolt		4
		Pawl Pin		2
11	JT9-JLH320-11	Pawl Spring (3, 6, 9 Ton)		2
12	JT9-JLH320-12	Pawl (3, 6, 9 Ton)		2
13	JT9-JLH320-13	Snap Ring (3, 6, 9 Ton)	Ø 10mm	2
14	JT9-JLH320-14	Disc Hub (3, 6, 9 Ton)		1
15	JT9-JLH320-15	Ratchet Disc (3, 6, 9 Ton)		1
16-1	JT9-JLH320-16-1	Brake Cover Assembly (3, 6, 9 Ton)		1
		Brake Cover		1
		Handle Case		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JLH-600WO-5 | Stock 376600

Parts List A - JLH-600 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
		Bushing		1
		Thread Housing		1
17-1	JT9-JLH320-17G	Acorn Nut (3, 6, 9 Ton)	M8	2
17A	JT9-JLH320-17AG	Lock Washer (3, 6, 9 Ton)	8mm	2
18	JT9-JLH80-18G	Lock Washer (0.75 to 9 Ton)	8mm	8
19	JT9-JLH80-19G	Acorn Nut (0.75 to 9 Ton)	M8	8
20-2	JT9-JLH320-20-2	Change Over Gear (3, 6, 9 Ton)		1
20-2L	JT9-JLH630-20L-2	Overload Limiter Assembly		1
		Overload Limiting Plate		1
		Change Over Gear		1
		Pressure Plate		1
		Dish Spring		1
		Washer		1
		Lock Washer		1
		Round Nut	M30x1	1
21	JT9-JLH320-21	Change Over Pawl (3, 6, 9 Ton)		1
22	JT9-JLH320-22	Spring Shaft (3, 6, 9 Ton)		1
23	JT9-JLH320-23	Spring (3, 6, 9 Ton)		1
24-1	JT9-JLH320-24-1	Lever Handle Assembly (3, 6, 9 Ton)		1
		Lever Handle		1
		Selector Lever		1
		Change Over Shaft		1
		Bolt		2
		Spring Seat		1
		Bushing		1
24A-1	JT9-JLH320-24A-1	Rubber Grip (3, 6, 9 Ton)		1
25	JT1-409	Socket Head Cap Screw (3, 6, 9 Ton)	M8 x 16	1
25A	JT9-JLH320-25AG	Lock Washer (2.5, 3, 6, 9 Ton)	8mm	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JLH-600WO-5 | Stock 376600

Parts List A - JLH-600 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
26-2	JT9-JLH320-26-2A	Stop Knob (3, 6, 9 Ton)		1
27-1	JT9-JLH320-27-1	Twisting Spring (3, 6, 9 Ton)		1
28-2	JT9-JLH320-28-2	Hand Wheel Assembly (3, 6, 9 Ton)		1
		Hand Wheel		1
		Steel Ball Spring		2
		Steel Ball		2
29-1	JT9-JLH320-29-1	Hand Wheel Cap (3, 6, 9 Ton)		1
30-1	JT9-JLH320-30-1	Hand Wheel Base Assembly (3, 6, 9 Ton)		1
		Hand Wheel Base		1
		Bushing		2
31-1	JT9-F001755	Lock Nut	M10	1
32-1	JT9-JLH80-32-1	Steel Cable Ring (3 to 9 Ton)		1
33	JT9-JLH80-33	Rivet (0.75 to 9 Ton)	3 x 6mm	4
34-1	JT9-LM000196	Name Plate JLH-600		1
37	JT9-JLH630-37-1	Safety Latch Kit		2
		Safety Latch		2
		Double Spring		2
		Socket Cap Screw	M6 x 33	2
		Lock Nut	M6	2
38-1	JT9-JLH630-38-1	Bottom Hook Assembly (incls. 35 & 36)		1
		Bottom Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Cap Screw	M6 x 33	1
		Lock Nut	M6	1
		Bottom Hook Holder		2
		Socket Cap Screw	M10 x 32	3
		Lock Nut	M10	3

mmToolParts
Big Time Experience. Small Town Service. .com

JET JLH-600WO-5 | Stock 376600

Parts List A - JLH-600 Lever Hoist (continued)

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
		Straight Pin	Ø8 x 18mm	2
		Idle Shaft		1
		Idle Sheave		1
		Needle Bearing		29
39	JT9-JLH320-39	Top Hook Shaft (3, 6, 9 Ton)		1
40	JT9-JLH630-40-1	Top Hook Assembly		1
		Top Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Cap Screw	M6 x 33	1
		Lock Nut	M6	1
		Top Hook Holder		2
		Rivet	10 x 34mm	3
41	JT9-JLH320-41	Chain Stop (3, 6, 9 Ton)		1
42	JT9-JLH320-42	Drive Shaft Washer (3, 6, 9 Ton)		1
43	JT9-JLH630-43	Socket Cap Screw (includes 43A nut, 43B washer) M10 x 30		3
		43A Lock Nut	M10	
		43B Washer	10mm	
44	JT9-JLH630-44	Straight Pin	Ø8 x 18	2
45	JT9-JLH630-45	Idle Shaft (6, 9T)		1
46	JT9-JLH630-46	Idle Sheave (6, 9T)		1
47	JT9-JLH630-47	Chain Pin		1
48	JT9-F001755	Lock Nut	M10	1
49	JT9-JLH320-49	Load Chain (3, 6, 9 Ton) - specify length	#100,Ø10 x 28mm	2
50	JT9-JLH320-50	Rubber Grip Fastening (3, 6, 9 Ton)		1
50A	JT9-JLH320-50A	Fastening Screw (3, 6, 9 Ton)		1
51	JT9-JLH900-51	Needle Bearing		29
	JT9-JLH-7040WL	Warning Label (not shown)	70x40mm	1
52	JT9-L100-WT	Warning Tag		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JLH-600WO-5 | Stock 376600

Parts List A - JLH-600 Lever Hoist - Notes

Lever Hoist | Original JET parts reference

Note: Top and bottom hooks are sold as an assembly only.

When ordering replacement chain (#49), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com