
JET JLP-300A-15 | Stock 287502

Diagram A - JLP-300A Lever Hoist

Lever Hoist | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET JLP-300A-15 | Stock 287502

Parts List A - JLP-300A Lever Hoist

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
02-1	JT9-JLP150A-02-1	Lock Nut (1.5T, 3T, 6T)	M10	1
04-1	JT9-JLP150A-04-1	Hand Wheel Assembly (1.5T, 3T, 6T)		1
5	JT9-JLP150A-05G	Hex Head Screw (1.5T, 3T, 6T)	M8	3
6	JT9-JLP150A-06G	Spring Washer (1.5T, 3T, 6T)	Ø8 mm	3
08-1	JT9-JLP150A-08-1	Rubber Grip (1.5T, 3T, 6T)		1
09-1	JT9-JLP150A-09-1	Lever Handle Assembly (1.5T, 3T, 6T)		1
11	JT9-JLP150A-11	Change Over Spring (1.5T, 3T, 6T)		1
12	JT9-JLP150A-12	Spring Shaft (1.5T, 3T, 6T)		1
13	JT9-JLP150A-13	Change Over Pawl (1.5T, 3T, 6T)		1
15	JT9-JLP150A-15	Change Over Gear (1.5T, 3T, 6T)		1
16	JT9-JLP300A-16G	Brake Cover Assembly		1
20	JT9-JLP150A-20	Friction Disc (1.5T, 3T, 6T)		2
21	JT9-JLP150A-21	Ratchet Disc (1.5T, 3T, 6T)		1
23	JT9-JLP150A-23	Brake Seat (1.5T, 3T, 6T)		1
24	JT9-JLP300A-24	Snap Ring (3T, 6T)	Ø11mm	2
25	JT9-JLP300A-25	Pawl (3T, 6T)		2
26	JT9-JLP300A-26	Pawl Spring (3T, 6T)		2
27	JT9-JLP300A-27	Lever Side Plate Assembly (3T, 6T)		1
28	JT9-JLP300A-28A	Load Sprocket (3T, 6T) (s/n 12043550 and higher)		1
29	JT9-JLP300A-29	Roller Set (Right and Left) (3T, 6T)	Ø5x6 mm	60
30-1	JT9-JLP300A-30-1	Driving Pinion (3T, 6T)		1
31	JT9-JLP300A-31	Stripper (3T, 6T)		1
32	JT9-JLP300A-32	Chain Guide Plate (3T, 6T)		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JLP-300A-15 | Stock 287502

Parts List A - JLP-300A Lever Hoist (continued)

Lever Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
34	JT9-JLP300A-34	Gear Side Plate Assembly (3T, 6T)		1
35	JT9-JLP300A-35A	Load Gear (3T, 6T) (s/n 12043550 and higher)		1
36	JT9-JLP300A-36	Snap Ring (3T, 6T)	Ø45 mm	1
38	JT9-JLP300A-38	Spur Gear Assembly (3T, 6T)		2
39	JT9-JLP300A-39G	Gear Cover Assembly (3T, 6T)		1
40	JT9-JLP300A-40G	Acorn Nut and Lock Washer	M12	8
41	JT9-JLP300A-41G	Top Hook Assembly (standard hook)		1
41	JT9-JLP300A-41PHG	Top Hook Assembly (ship yard hook)		1
43	JT9-JLP300A-43	Top Hook Shaft (3T, 6T)		1
44	JT9-JLP300A-44	Load Chain - specify length (3T, 6T)	Ø10x30 mm	1
45	JT9-JLP75A-45	Chain Stop (0.75T, 1.5T, 3T, 6T)		1
46	JT9-F001755	Load Pin Nut	M10	1
48	JT9-JLP300A-48	Load Pin		1
49	JT9-JLP300A-49G	Bottom Hook Assembly (standard hook)		1
49	JT9-JLP300A-49PHG	Bottom Hook Assembly (ship yard hook)		1
63	JT9-JLP300A-63-1	Safety Latch Kit		2
64	JT9-JLP75A-64	Name Plate Rivet (0.75T, 1.5T, 3T, 6T)	3x6 mm	4
65	JT9-LM000052	Name Plate JLP-300A		1
66-1	JT9-JLP150A-66-1	Stop Knob (1.5T, 3T, 6T)		1
67	JT9-JLP75A-67	Twisting Spring (0.75T, 1.5T, 3T, 6T)		1
68	JT9-JLP150A-68	Hand Wheel Base Assembly (1.5T, 3T, 6T)		1
69	JT9-JLP75A-69	Rubber Grip Fastening (0.75T,1.5T,3T,6T)		1
70	JT9-JLP75A-70	Fastening Screw (0.75T,1.5T,3T,6T)		1
71	JT9-JLP150A-71	Snap Ring (1.5T, 3T, 6T)		1

Note: All parts mentioned as assembly are sold as an assembly only.

When ordering replacement chain (#44), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com