
JET JSJ-5T | Stock 454450

Diagram A - Service Jack

Service Jack | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET JSJ-5T | Stock 454450

Parts List A - Service Jack

Service Jack | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	JSJ5M-18	Frame and Lift Arm Assembly		1
2	JSJ5T-2	Front Wheel		2
3	JSJ5M-16	Flat Washer	Ø 22.5 x 2mm	2
4	JSJ5M-15	Snap Ring	Ø 19mm	4
5	JSJ3T-5	Grease Fitting		3
6	JSJ5T-6	Saddle		1
7	JSJ5M-12	Link Rod		2
8	JSJ5M-11	Link Rod Bolt		2
9	JSJ5M-8	Lock Washer	M20	2
10	JSJ5M-9	Hex Nut	M20	2
11	JSJ5M-21	Spring		1
12	TS-2210161	Hex Cap Screw	M10 x 16mm	1
13	TS-1491031	Hex Cap Screw	M10 x 25mm	2
14	TS-2361101	Lock Washer	M10	2
15	JSJ5T-15	Shaft		1
16	JSJ5T-16	Rear Wheel Assembly		2
17	JSJ3M-02	Hex Nut	M12 x 1.25mm	4
18	JSJ3M-32	Snap Ring	Ø 18mm	2
19	JSJ5M-33	Shaft		1
20	TS-1550061	Flat Washer	M8	1
21	JSJ3T-21	Pin	Ø 3 x 18mm	2
22	JSJ5M-36	Link		2
23	JSJ3T-23	Snap Ring	Ø 12mm	2
24	JSJ3T-24	Pedal Pin		1
25	JSJ3M-26	Spring		1
26	JSJ3T-26	Handle Socket		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JSJ-5T | Stock 454450

Parts List A - Service Jack (continued)

Service Jack | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
27	JSJ3M-29	Pedal		1
28	JSJ3M-40	Lock Nut	M10	1
29	JSJ3M-41	Flat Washer	M10	2
30	JSJ3M-42	Hex Cap Screw	M10 x 35mm	1
31	JSJ3T-31	Control Rod		1
32	JSJ3T-32	Handle Sleeve		2
33	JSJ3T-33	Fixing Ring		1
34	JSJ3T-34	Spring		1
35	JSJ3M-53	Flat Washer	Ø 10mm	1
36	JSJ3T-36	Rod Joint		1
37	JSJ3T-137	Cotter Pin	Ø 4 x 20mm	1
38	JSJ3T-38	Handle		1
39	JSJ3T-39	Knob		1
40	JSJ3T-40	Lock Pin	Ø 4 x 40mm	1
41	JSJ10M-28	Universal Joint Assembly		1
42	JSJ3T-42	Pin	Ø 3 x 20mm	1
43	JSJ3M-43	Spring		1
44	JSJ3T-44	Lock Pin	Ø 3 x 18mm	1
45	JSJ3T-45	Release Rod		1
46	JSJ3T-46	Lock Pin	Ø 4 x 20mm	2
47	JSJ5T-47	Cover		1
	JSJ5T-200	Hydraulic Cylinder Assembly (includes index #48 thru 76)		
48	JSJ3T-48	Pump Plunger Pin		1
49	JSJ3T-49	Pump Plunger		1
50	JSJ3T-50	Nylon Gasket *	Ø 14mm	2
51	JSJ3T-51	O-Ring *	Ø 14 x 2.65mm	2

mmToolParts
Big Time Experience. Small Town Service. .com

JET JSJ-5T | Stock 454450

Parts List A - Service Jack (continued)

Service Jack | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
52	JSJ3T-52	Release Pin		1
53	JSJ3T-53	Seal *		1
54	SB-6MM	Steel Ball	Ø 6mm	2
55	SB-4MM	Steel Ball	Ø 4mm	1
56	JSJ3T-56	Safety Valve Ball Seat		1
57	JSJ3T-57	Safety Valve Spring		1
58	JSJ3T-58	Safety Valve Adjusting Screw		1
59	JSJ3T-59	Seal *		1
60	JSJ3T-60	Safety Valve Screw		1
61	JSJ3T-61	Spring		1
62	SB-9MM	Steel Ball	Ø 9mm	1
63	JSJ3T-63	Spring		1
64	JSJ3T-64	Copper Washer		1
65	TS-1506011	Socket Head Cap Screw	M12 x 20mm	1
66	JSJ3T-66	Oil Filler Plug		1
67	JSJ5T-67	Oil Tank Assembly		1
68	JSJ5T-68	Snap Ring	Ø 40mm	1
69	JSJ5T-69	O-Ring Retainer		1
70	JSJ5T-70	O-Ring *	Ø 46.2 x 5.7mm	1
71	JSJ5T-71	Seal Washer *		1
72	JSJ5T-72	Piston Ring		1
73	JSJ5T-73	Ram		1
74	JSJ5T-74	Bushing		2
75	JSJ5T-75	O-Ring *	Ø 51.5 x 4.6mm	1
76	JSJ5T-76	Snap Ring		1
	JSJ5T-RK	Repair Kit for JSJ-5T		

* Parts marked with an asterisk are included in the repair kit.

mmToolParts
Big Time Experience. Small Town Service. .com