
JET JWL-1015VS | Stock 719110

Diagram A - JWL-1015VS Lathe

Original JET parts reference | Match model, voltage and serial-number notes

16.1.1 JWL-1015VS Lathe – Exploded View



mmToolParts
Big Time Experience. Small Town Service. .com

JET JWL-1015VS | Stock 719110

Parts List A - JWL-1015VS Lathe

Original JET parts reference | Match model, voltage and serial-number notes

Ref.	Part number	Description	Size	Qty.
	**	Headstock Assembly (includes #1 thru #20)		1
1	JT9-JWL1440-102	Faceplate	3”	1
2	JT9-JML-3	Spur Center	MT2	1
2A	JT9-JML-3A	Center Point for Spur Center		1
3	JT9-JML-4	Spindle	1” x 8 TPI	1
4	JT9-JML-5	Key	5x25mm	1
5	JT9-BB-6005VV	Ball Bearing	6005VV	1
6	JT9-JML-20	V-Belt	240J	1
7	JT9-TS-0267041	Socket Set Screw	1/4”-20x3/8”	2
8	JT9-JWL1015VS-108	Spindle Pulley		1
9	JT9-JWL1015-109	Headstock		1
10	JT9-JWL1015-110	Pin		1
11	JT9-JML1014-187	C-Ring	STW-9	1
12	JT9-JML1014-188	Spring		1
13	JT9-JML1014-189	Index Pin		1
14	JT9-JWL1221VS-123	Handwheel		1
15	JT9-TS-0267021	Set Screw	1/4”-20x1/4”	4
16	CM9-BB-6004VV	Ball Bearing	6204VV	1
17	JT9-JWL1015VS-117	Speed Label		1
18	JT9-JWL1015-118	Pulley Access Door		1
19	JT9-JWL1015-119	Spring		1
20	JT1-2431	JWL1015-120 WAVE WASHER	BWW629	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JWL-1015VS | Stock 719110

Parts List A - JWL-1015VS Lathe (continued)

Original JET parts reference | Match model, voltage and serial-number notes

Ref.	Part number	Description	Size	Qty.
21	JT9-JWL1015-121	Bed		1
22	JT9-TS-0207061	Socket Head Cap Screw	1/4”-20x1”	4
23	JT9-TS-0720071	Lock Washer	1/4”	4
24	JT9-JWL1015-124	Socket Head Button Screw	#10-24x1/4”	2
25	JT9-JWL1015-125	Motor Access Door		1
26	JT9-JWL1015VS-126	I.D Label		1
27	JT9-TS-0267041	Socket Set Screw	1/4”-20x3/8”	2
28	**	JET Stripe		1
29	JT9-TS-0051051	Hex Cap Screw	5/16”-18x1”	1
30	JT9-TS-0640081	Nylon Lock Hex Nut	5/16”-18	1
31	JT9-JWL1015VS-131	Motor Pulley		1
32	JT9-TS-0254021	Socket Head Button Screw	1/4”-20x1/2”	2
33	JT9-JML-42	Tool Rest	6”	1
34	JT9-JWL1015-134	Motor Bracket		1
35	JT9-JWL1221VS-266	Rubber Cover		1
36	JT9-JWL1015-136	Bushing		1
37	JT9-JWL1015-137	Lock Handle Assembly, Motor Plate		1
38	JT9-JWL1015VS-138	Motor Label		1
39	JT9-JWL1015VS-139	Motor	1/2 HP	1
	JT9-JWL1015VS-MCB	Motor Carbon Brush with Cap (not shown)		2
	JT9-JWL1015VS-MFC	Motor Fan Cover (not shown)		1
	JT9-JWL1015VS-MF	Motor Fan (not shown)		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JWL-1015VS | Stock 719110

Parts List A - JWL-1015VS Lathe (continued)

Original JET parts reference | Match model, voltage and serial-number notes

Ref.	Part number	Description	Size	Qty.
	JT9-JWL1015-TBA	Toolrest Base Assembly (includes #40 thru #47)		2
40	JT9-JML-49	C-Ring	STW-12	2
41	JT9-JWL1015-141	Tool Rest Body		1
43	JT9-JML-59A	Lock Handle Assembly	5/16”-18x3/4”	2
44	JT9-JML-50	Eccentric Locking Rod		1
45	JT9-JML-43	Bolt		1
46	JT9-JML-44	Clamp		2
47	JT9-JML-81	Clamp Nut		2
	JT9-JWL1015-TA	Tailstock Assembly (includes #15,43,46 thru #57)		1
48	JT9-JWL1015-148	Tailstock		1
49	JT9-TS-0255031	Socket Head Button Screw	5/16”-18x5/8”	1
50	JT9-JML-58	Eccentric Rod, Tailstock		1
51	JT9-JWL1015-151	Lead Screw		1
52	JT9-JML-55	Quill		1
53	JT9-JML-64	Bolt		1
54	JT9-JWL1221VS-222	Handle		1
55	JT9-JWL1221VS-223	Handwheel		1
56	JT9-JML-63	C-Ring	STW-10	1
57	JT9-TS-0680031	Flat Washer	5/16”	2
58	JT9-708331	Live Center Assembly (includes #59 thru #62)		1
59	JT9-JML-52	Live Center Head		1
60	JT9-JML-52A	Center Point for Live Center		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET JWL-1015VS | Stock 719110

Parts List A - JWL-1015VS Lathe (continued)

Original JET parts reference | Match model, voltage and serial-number notes

Ref.	Part number	Description	Size	Qty.
61	JT9-BB-6002ZZ	Ball Bearing	6002ZZ	1
62	JT9-JML-54	Live Center Shaft		1
	JT9-JWL1015VS-CA	Controller Assembly (includes #63 thru #75)		1
63	JT9-JWL1015VS-163	Power Cord		1
64	JT9-JWL1221VS-320	Strain Relief	6B3-2	2
65	JT9-JWL1015VS-165	Plate		1
66	JT9-JWL1015VS-166	Switch Cover		1
67	JT9-JWL1015VS-167	Tapping Screw	M3x12	4
68	JT9-JWL1015VS-168	Control Potentiometer Assembly		1
69	JT9-JWL1221VS-308	On-Off Switch		1
70	JT9-JWL1015VS-170	Tapping Screw		2
71	JT9-JWL1015VS-171	Circuit Board Assembly		1
72	JT9-JWL1221VS-302	Tapping Screw	M3x19	4
73	JT9-JWL1015VS-174	Connect Cord (VR to PC board; not shown)		1
74	JT9-JWL1221VS-324	Connect Cord (Power cord to PC board; not shown)		1
75	JT9-JWL1015VS-175	Switch Cover		1
77	JT9-JWL1015-172	Clamp	5/16”	2
78	JT9-JWL1221VS-276	Clamp	1/2”	1
79	JT9-TS-081C022	Pan Head Screw	#10-24x3/8”	2
80	JT9-JML-11	Knockout Rod		1
81	JT9-JWL1221VS-211	Warning Label (not shown)		1
82	**	Model Decal 1015		1

** These parts are shown for reference only and are not available for order individually. Non-proprietary parts, such as fasteners, can usually be found at local hardware stores.

mmToolParts
Big Time Experience. Small Town Service. .com