
# JET L-100-100WO-10 | Stock 102100

## Diagram A - L100-100 Chain Hoist

Chain Hoist | Original JET parts reference




mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-100WO-10 | Stock 102100

## Parts List A - L100-100 Chain Hoist

Chain Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | JT9-L100-100-1 | Top Hook Assembly | | 1 |
| | | Top Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M4x20 | 1 |
| | | Lock Nut | M4 | 1 |
| | | Top Hook Holder | | 1 |
| | | Rivet | 5x20 mm | 2 |
| 2 | JT9-L100-100-2 | Safety Latch Assembly | | 2 |
| | | Safety Latch | | 2 |
| | | Double Spring | | 2 |
| | | Socket Head Cap Screw | M4x20 | 2 |
| | | Lock Nut | M4 | 2 |
| 3 | JT9-L100-100-3 | Top Hook Shaft | | 1 |
| 4 | JT9-L100-100-4 | Split Pin | 2.5x20 mm | 1 |
| 5 | JT9-L100-100-5 | Bottom Hook Assembly | | 1 |
| | | Bottom Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M4x20 | 1 |
| | | Lock Nut | M4 | 1 |
| | | Rivet | 5x20 mm | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-100WO-10 | Stock 102100

## Parts List A - L100-100 Chain Hoist (continued)

Chain Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 6 | JT9-L100-100-6 | Bottom Hook Shaft | | 1 |
| 7 | JT9-F001753 | Lock Nut | M6 | 1 |
| 8 | JT9-L100-100-8G | Hand Wheel Cover Assembly | | 1 |
| | | Hand Wheel Cover | | 1 |
| | | Hand Chain Guide | | 2 |
| 8A | JT9-L100-50-8A | Warning Label | | 1 |
| 9 | JT9-L100-100-9-1 | Wheel Stopper | M8 | 1 |
| 10A | JT1-2787 | Bearings | | 1 |
| 12 | JT9-L100-100-12 | Hand Chain - specify length | 5x25 mm | 1 |
| 13 | JT9-L100-100-13 | Hand Chain Connecting Link | | 1 |
| 14L | JT9-00-100WO-14-1L | Overload Limiter Assembly | | 1 |
| | | Overload Limiter Knob | | 1 |
| | | Brake Disc | | 2 |
| | | Hand Chain Wheel | | 1 |
| | | Bushing in Hand Chain Wheel | | 1 |
| | | Disc Spring Plate | | 1 |
| | | Disc Spring | | 1 |
| | | Disc Spring Stopper | | 1 |
| | | Lock Nut | | 1 |
| 15 | JT9-L100-100-15 | Snap Ring | 10 mm | 2 |
| 16 | JT9-L100-100-16 | Pawl | | 2 |
| 17 | JT9-L100-100-17 | Pawl Spring | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-100WO-10 | Stock 102100

## Parts List A - L100-100 Chain Hoist (continued)

Chain Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 18 | JT9-L100-100-18-1 | Ratchet Disc Assembly | | 1 |
| | | Ratchet Disc | | 1 |
| | | Ratchet Bushing | | 1 |
| 19 | JT9-L100-100-19-1 | Disc Hub | | 1 |
| 20 | JT9-L100-300-20-1 | Wheel Side Plate Assembly | | 1 |
| | | Wheel Side Plate | | 1 |
| | | Stay Bolt | | 3 |
| | | Pawl Pin | | 2 |
| | | Brake Cover | | 1 |
| | | Double Seal Ball Bearing | d30xD55x13 mm | 1 |
| 21 | JT9-L100-100-21 | Double Seal Ball Bearing | d30xD55x13 mm | 1 |
| 21A | JT9-L100-100-21A | Double Seal Ball Bearing | d25xD47x12 mm | 1 |
| 21B | JT9-L100-100-21B | Double Seal Ball Bearing | d10xD30x9 mm | 1 |
| 22 | JT9-L100-100-22 | Gear Side Plate Assembly | | 1 |
| | | Gear Side Plate | | 1 |
| | | Bushing | | 2 |
| | | Double Seal Ball Bearing | d25xD47x12 mm | 1 |
| 23 | JT9-L100-100-23 | Load Gear | | 1 |
| 24A | JT1-2788 | Drive Shaft | | 1 |
| 25 | JT9-L100-100-25G | Gear Case Assembly | | 1 |
| | | Gear Case | | 1 |
| | | Bushing | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-100WO-10 | Stock 102100

## Parts List A - L100-100 Chain Hoist (continued)

Chain Hoist | Original JET parts reference

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| | | Double Seal Bearing | d10xD30x9 mm | 1 |
| 26 | JT9-TS-2361082 | Lock Washer (Black Oxide) | 8mm | 3 |
| 26A | JT9-TS-2361082 | Lock Washer (Black Oxide) | 8mm | 3 |
| 27 | JT9-F001754 | Acorn Nut ( (Black Oxide) | M8 | 3 |
| 27A | JT9-F001754 | Acorn Nut (Black Oxide) | M8 | 3 |
| 28 | JT9-L100-100-28 | Rivet | 3x6 mm | 4 |
| 29 | JT9-LM000018 | Name Plate, L100-100 with overload | | 1 |
| 30 | JT9-L100-100-30 | Spur Gear Assembly | | 2 |
| | | Spur Gear | | 2 |
| | | Pinion Gear | | 2 |
| 31 | JT9-L100-100-31 | Load Sheave | | 1 |
| 31A | JT9-L100-50-31A | C-Clip | 21 mm | 1 |
| 31B | JT9-L100-50-31B | Needle Bearing HK1412 | d14xD21x12 mm | 1 |
| 32 | JT9-L100-100-32 | Guide Roller | | 2 |
| 33 | JT9-L100-100-33 | Stripper | | 1 |
| 34 | JT9-L100-100-34 | Chain Anchor Plate | | 1 |
| 35 | JT9-L100-100-35 | Chain Anchor Pin | | 1 |
| 36 | JT9-L100-100-36 | Split Pin | 2x15 mm | 1 |
| 37 | JT9-L100-100-37 | Load Chain - specify length | 6.3x19 mm | 1 |
| 47 | JT9-L100-50-47 | Snap Ring | 22 mm | 1 |
| 48 | JT9-L100-100-48G | Dust Cover | | 1 |
| | JT9-L100-WT | Warning Tag (not shown) | | 1 |

Note: When ordering replacement chain (Index #12, #37), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com