
# JET L-100-1500WO-30 | Stock 109130

## Diagram A - L100-1500 Chain Hoist

For serial no. 15070088 and higher




mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-1500WO-30 | Stock 109130

## Parts List A - L100-1500 Chain Hoist

For serial no. 15070088 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | JT9-L100-1500-1 | Top Hook Assembly | | 1 |
| | | Top Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M5x30 | 1 |
| | | Lock Nut | M6 | 1 |
| | | Top Hook Holder | | 1 |
| | | Hook Collar Bushing | | 1 |
| | | Idle Shaft | | 1 |
| | | Idle Sheave | | 2 |
| | | Needle Bearing | | 2 |
| | | Socket Head Cap Screw | M12x40 | 1 |
| | | Lock Nut | M12 | 2 |
| | | Lock washer | M12 | 2 |
| 2 | JT9-L100-1500-2 | Safety Latch Assembly | | 2 |
| | | Safety Latch | | 2 |
| | | Double Spring | | 2 |
| | | Socket Head Cap Screw | M5x30 | 2 |
| | | Lock Nut | M5 | 2 |
| 3 | JT9-L100-500-3 | Top Hook Shaft | | 1 |
| 4 | JT9-L100-500-4 | Split Pin | 2.5x22 mm | 1 |
| 5 | JT9-L100-1500-5 | Bottom Hook Assembly | | 1 |
| | | Bottom Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M6x30 | 1 |
| | | Lock Nut | M6 | 1 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-1500WO-30 | Stock 109130

## Parts List A - L100-1500 Chain Hoist (continued)

For serial no. 15070088 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| | | Idle Shaft | | 1 |
| | | Idle Sheave | | 3 |
| | | Needle Bearing | | 3 |
| | | Socket Head Cap Screw | | 3 |
| | | Lock Nut | | 3 |
| | | Lock Washer | | 3 |
| | | Hook Collar Bushing | | 1 |
| | | Bottom Hook Holder | | 1 |
| 8 | JT9-L100-500-8G | Hand Wheel Cover Assembly | | 1 |
| | | Hand Wheel Cover | | 1 |
| | | Hand Chain Guide | | 2 |
| 8A | JT9-L100-50-8A | Warning Label | | 1 |
| 9 | JT9-L100-100-9-1 | Wheel Stopper | M8 | 1 |
| 10A | JT1-2787 | Bearings | | 1 |
| 12 | JT9-L100-100-12 | Hand Chain - specify length | 5x25 mm | 2 |
| 13 | JT9-L100-100-13 | Hand Chain Connecting Link | | 2 |
| 14L | JT9-100-1500WO-14L | Overload Limiter Assembly | | 2 |
| | | Overload Limiter Knob | | 2 |
| | | Brake Disc | | 4 |
| | | Hand Chain Wheel | | 2 |
| | | Bushing in Hand Chain Wheel | | 2 |
| | | Disc Spring Plate | | 2 |
| | | Disc Spring | | 2 |
| | | Disc Spring Stopper | | 2 |
| | | Lock Nut | | 2 |
| 15 | JT9-L100-100-15 | Snap Ring | 10 mm | 2 |
| 16 | JT9-L100-100-16 | Pawl | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-1500WO-30 | Stock 109130

## Parts List A - L100-1500 Chain Hoist (continued)

For serial no. 15070088 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 17 | JT9-L100-100-17 | Pawl Spring | | 2 |
| 18 | JT9-L100-500-18-1 | Ratchet Disc Assembly | | 1 |
| | | Ratchet Disc | | 1 |
| | | Ratchet Bushing | | 1 |
| 19 | JT9-L100-500-19-1 | Disc Hub | | 1 |
| 20 | JT9-L100-500-20-1 | Wheel Side Plate Assembly | | 1 |
| | | Wheel Side Plate | | 1 |
| | | Stay Bolt | | 3 |
| | | Pawl Pin | | 2 |
| | | Brake Cover | | 1 |
| | | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 21 | JT9-L100-500-21 | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 21A | JT9-L100-500-21 | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 21B | JT9-L100-500-21B | Double Seal Ball Bearing | d12xD32x10 mm | 1 |
| 22 | JT9-L100-500-22 | Gear Side Plate Assembly | | 1 |
| | | Gear Side Plate | | 1 |
| | | Bushing | | 2 |
| | | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 23 | JT9-L100-500-23 | Load Gear | | 1 |
| 24A | JT1-2796 | Drive Shaft | | 1 |
| 25 | JT9-L100-500-25G | Gear Case Assembly | | 1 |
| | | Gear Case | | 1 |
| | | Bushing | | 2 |
| | | Double Seal Bearing | d12xD32x10 mm | 1 |
| 26 | JT9-F002118 | Lock Washer (Black Oxide) | 12 mm | 3 |
| 26A | JT1-3001 | Lock Washer (Black Oxide) | 8 mm | 3 |
| 27 | JT1-2998 | Acorn Nut (Black Oxide) | M12 | 3 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-1500WO-30 | Stock 109130

## Parts List A - L100-1500 Chain Hoist (continued)

For serial no. 15070088 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 27A | JT9-F001754 | Acorn Nut (Black Oxide) | M8 | 3 |
| 28 | JT9-L100-100-28 | Rivet | 3x6 mm | 4 |
| 29 | JT9-LM000030 | Name Plate, L100-1500 with overload | | 1 |
| 30 | JT1-3000 | Spur Gear Assembly | | 2 |
| | | Spur Gear | | 2 |
| | | Pinion Gear | | 2 |
| 31 | JT9-L100-500-31 | Load Sheave | | 1 |
| 31A | JT9-L100-500-31A | C-Clip | 24 mm | 1 |
| 31B | JT9-L100-500-31B | Needle Bearing HK1715 | d17xD24x15 mm | 1 |
| 32 | JT9-L100-500-32 | Guide Roller | | 2 |
| 33 | JT9-L100-500-33 | Stripper | | 1 |
| 34 | JT9-L100-500-34 | Chain Anchor Plate | | 1 |
| 35 | JT9-L100-500-35 | Chain Anchor Pin | | 1 |
| 36 | JT9-L100-500-36 | Split Pin | 2x18 mm | 1 |
| 37 | JT9-L100-500-37 | Load Chain - specify length | 9x27mm | 1 |
| 38 | JT1-3002 | Top Hook Pin | | 1 |
| 39 | JT9-F001755 | Lock Nut | M10 | 1 |
| 42 | JT1-3003 | Bottom Idle Shaft | | 1 |
| 42A | JT1-3004 | Idle Shaft | | 1 |
| 43 | JT9-L100-1500-43 | Idle Sheave | | 5 |
| 45 | JT1-3005 | Top Hook Shaft | | 1 |
| 46 | JT1-3006 | Bottom Hook Shaft | | 1 |
| 47A | JT1-2789 | Snap Ring | 42mm | 4 |
| 47B | JT1-3007 | Snap Ring | 35mm | 4 |
| 48 | JT9-L100-500-48G | Dust Cover | | 1 |
| 50 | JT1-3008 | Top Hook Pin | | 1 |
| 51 | JT1-3009 | Lock Nut | M16 | 1 |
| | JT9-L100-WT | Warning Tag (not shown) | | 1 |

Note: When ordering replacement chain (Index #12, #37), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com