
# JET L-100-200WO-30 | Stock 206130

## Diagram A - L100-200 Chain Hoist

For serial no. 15070001 and higher




mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-200WO-30 | Stock 206130

## Parts List A - L100-200 Chain Hoist

For serial no. 15070001 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 1 | JT9-L100-200-1 | Top Hook Assembly | | 1 |
| | | Top Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M5x25 | 1 |
| | | Lock Nut | M5 | 1 |
| | | Top Hook Holder | | 1 |
| | | Rivet | 6x24 mm | 2 |
| 2 | JT9-L100-200-2 | Safety Latch Assembly | | 2 |
| | | Safety Latch | | 2 |
| | | Double Spring | | 2 |
| | | Socket Head Cap Screw | M5x25 | 2 |
| | | Lock Nut | M5 | 2 |
| 3 | JT9-L100-200-3 | Top Hook Shaft | | 1 |
| 4 | JT9-L100-100-4 | Split Pin | 2.5x20 mm | 1 |
| 5 | JT9-L100-200-5 | Bottom Hook Assembly | | 1 |
| | | Bottom Hook | | 1 |
| | | Safety Latch | | 1 |
| | | Double Spring | | 1 |
| | | Socket Head Cap Screw | M5x25 | 1 |
| | | Lock Nut | M5 | 1 |
| | | Rivet | 6x24 mm | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-200WO-30 | Stock 206130

## Parts List A - L100-200 Chain Hoist (continued)

For serial no. 15070001 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 6 | JT9-L100-200-6 | Bottom Hook Shaft | | 1 |
| 7 | JT9-F001754 | Lock Nut | M8 | 1 |
| 8 | JT9-L100-200-8G | Hand Wheel Cover Assembly | | 1 |
| | | Hand Wheel Cover | | 1 |
| | | Hand Chain Guide | | 2 |
| 8A | JT9-L100-50-8A | Warning Label | | 1 |
| 9 | JT9-L100-100-9-1 | Wheel Stopper | M8 | 1 |
| 10A | JT1-2787 | Bearings | | 1 |
| 12 | JT9-L100-100-12 | Hand Chain - specify length | 5x25 mm | 1 |
| 13 | JT9-L100-100-13 | Hand Chain Connecting Link | | 1 |
| 14L | JT9-00-200WO-14-1L | Overload Limiter Assembly | | 1 |
| | | Overload Limiter Knob | | 1 |
| | | Brake Disc | | 2 |
| | | Hand Chain Wheel | | 1 |
| | | Bushing in Hand Chain Wheel | | 1 |
| | | Disc Spring Plate | | 1 |
| | | Disc Spring | | 1 |
| | | Disc Spring Stopper | | 1 |
| | | Lock Nut | | 1 |
| 15 | JT9-L100-100-15 | Snap Ring | 10 mm | 2 |
| 16 | JT9-L100-100-16 | Pawl | | 2 |
| 17 | JT9-L100-100-17 | Pawl Spring | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-200WO-30 | Stock 206130

## Parts List A - L100-200 Chain Hoist (continued)

For serial no. 15070001 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| 18 | JT9-L100-200-18-1 | Ratchet Disc Assembly | | 1 |
| | | Ratchet Disc | | 1 |
| | | Ratchet Bushing | | 1 |
| 19 | JT9-L100-200-19-1 | Disc Hub | | 1 |
| 20 | JT9-L100-200-20-1 | Wheel Side Plate Assembly | | 1 |
| | | Wheel Side Plate | | 1 |
| | | Stay Bolt | | 3 |
| | | Pawl Pin | | 2 |
| | | Brake Cover | | 1 |
| | | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 21 | JT9-L100-500-21 | Double Seal Ball Bearing | d35xD62x14 mm | 1 |
| 21A | JT9-L100-100-21 | Double Seal Ball Bearing | d30xD55x13 mm | 1 |
| 21B | JT9-L100-500-21B | Double Seal Ball Bearing | d12xD32x10 mm | 1 |
| 22 | JT9-L100-200-22 | Gear Side Plate Assembly | | 1 |
| | | Gear Side Plate | | 1 |
| | | Bushing | | 2 |
| | | Double Seal Ball Bearing | d30xD55x13 mm | 1 |
| 23 | JT9-L100-200-23 | Load Gear | | 1 |
| 24A | JT1-2791 | Drive Shaft | | 1 |
| 25 | JT9-L100-200-25G | Gear Case Assembly | | 1 |
| | | Gear Case | | 1 |
| | | Bushing | | 2 |

mmToolParts
Big Time Experience. Small Town Service. .com

# JET L-100-200WO-30 | Stock 206130

## Parts List A - L100-200 Chain Hoist (continued)

For serial no. 15070001 and higher

| Ref. | Part number | Description | Size | Qty. |
|---|---|---|---|---|
| | | Double Seal Bearing | 12x32x10 mm | 1 |
| 26 | JT9-F002116 | Lock Washer (Black Oxide) | 10mm | 3 |
| 26A | JT9-F002114 | Lock Washer (Black Oxide) | 8mm | 3 |
| 27 | JT9-F001755 | Acorn Nut ((Black Oxide) | M10 | 3 |
| 27A | JT9-F001754 | Acorn Nut (Black Oxide) | M8 | 3 |
| 28 | JT9-L100-100-28 | Rivet | 3x6 mm | 4 |
| 29 | JT9-LM000022 | Name Plate, L100-200 with overload | | 1 |
| 30 | JT9-L100-200-30 | Spur Gear Assembly | | 2 |
| | | Spur Gear | | 2 |
| | | Pinion Gear | | 2 |
| 31 | JT9-L100-200-31 | Load Sheave | | 1 |
| 31A | JT9-L100-500-31A | C-Clip | 24 mm | 1 |
| 31B | JT9-L100-500-31B | Needle Bearing HK1715 | 17x42x15 mm | 1 |
| 32 | JT9-L100-200-32 | Guide Roller | | 2 |
| 33 | JT9-L100-200-33 | Stripper | | 1 |
| 34 | JT9-L100-200-34 | Chain Anchor Plate | | 1 |
| 35 | JT9-L100-200-35 | Chain Anchor Pin | | 1 |
| 36 | JT9-L100-100-36 | Split Pin | 2x15 mm | 1 |
| 37 | JT9-L100-200-37 | Load Chain - specify length | 8x24mm | 1 |
| 47 | JT9-L100-300-47 | Snap Ring | 28 mm | 1 |
| 48 | JT9-L100-200-48G | Dust Cover | | 1 |
| | JT9-L100-WT | Warning Tag (not shown) | | 1 |

Note: When ordering replacement chain (Index #12, #37), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com