
JET L-100-250WO-20 | Stock 101250

Diagram A - L100-250 Chain Hoist

Chain Hoist | Original JET parts reference



mmToolParts
Big Time Experience. Small Town Service. .com

JET L-100-250WO-20 | Stock 101250

Parts List A - L100-250 Chain Hoist

Chain Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
1	JT9-L100-25-1	Top Hook Assembly		1
		Top Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Head Cap Screw	M4x20	1
		Lock Nut	M4	1
		Top Hook Holder		1
		Rivet	4x14 mm	2
2	JT9-L100-25-2	Safety Latch Assembly		2
		Safety Latch		2
		Double Spring		2
		Socket Head Cap Screw	M4x20	2
		Lock Nut	M4	2
3	JT9-L100-25-3	Top Hook Shaft		1
4	JT9-L100-25-4	Split Pin	2.5x20 mm	1
5	JT9-L100-25-5	Bottom Hook Assembly		1
		Bottom Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Head Cap Screw	M4x20	1
		Lock Nut	M4	1
		Rivet	5x20 mm	2
6	JT9-L100-25-6	Bottom Hook Shaft		1
7	JT9-F001752	Lock Nut	M5	1
8	JT9-L100-25-8G	Hand Wheel Cover Assembly		1
		Hand Wheel Cover		1
		Hand Chain Guide		
8A	JT9-L100-25-8A	Warning Label		1
9	JT1-2794	Wheel Stopper	M5	1

mmToolParts
Big Time Experience. Small Town Service. .com

JET L-100-250WO-20 | Stock 101250

Parts List A - L100-250 Chain Hoist (continued)

Chain Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
10A	JT1-2792	Bearings		1
12	JT9-L100-25-12	Hand Chain - specify length	3x15 mm	1
13	JT9-L100-25-13	Hand Chain Connecting Link		1
14L	JT9-L100-25WO-14L	Overload Limiter Assembly		1
		Overload Limiter Knob		1
		Brake Disc		2
		Hand Chain Wheel		1
		Bushing in Hand Chain Wheel		1
		Disc Spring Plate		1
		Disc Spring		1
		Disc Spring Stopper		1
		Lock Nut		1
15	JT9-L100-25-15	Snap Ring	5 mm	2
16	JT9-L100-25-16	Pawl		2
17	JT9-L100-25-17	Pawl Spring		2
18	JT9-L100-25-18-1	Ratchet Disc Assembly		1
		Ratchet Disc		1
		Ratchet Bushing		1
19	JT9-L100-25-19-1	Disc Hub		1
20	JT9-L100-25-20-1	Wheel Side Plate Assembly		1
		Wheel Side Plate		1
		Pawl Pin		2
		Brake Cover		1
		Double Seal Ball Bearing	d25xD42x9 mm	1
21	JT9-L100-25-21	Double Seal Ball Bearing	d20xD37x9 mm	1
21A	JT9-L100-25-21A	Double Seal Ball Bearing	d25xD42x9 mm	1
21B	JT9-L100-25-21B	Double Seal Ball Bearing	d6xD15x5 mm	1
22	JT9-L100-25-22	Gear Side Plate Assembly		1
		Gear Side Plate		1

mmToolParts
Big Time Experience. Small Town Service. .com

JET L-100-250WO-20 | Stock 101250

Parts List A - L100-250 Chain Hoist (continued)

Chain Hoist | Original JET parts reference

Ref.	Part number	Description	Size	Qty.
		Bushing		2
		Double Seal Ball Bearing	d25xD42x9 mm	1
23	JT9-L100-25-23	Load Gear		1
24A	JT1-2793	Drive Shaft		1
25	JT9-L100-25-25G	Gear Case Assembly		1
		Gear Case		1
		Bushing		2
		Double Seal Ball Bearing	d10xD22x6 mm	1
26	JT9-TS-2361062	Lock Washer (Black Oxide)	6mm	3
26A	JT9-TS-2361062	Lock Washer (Black Oxide)	6mm	3
27	JT9-F001753	Acorn Nut (Black Oxide)	M6	3
27A	JT9-F001753	Acorn Nut (Black Oxide)	M6	3
28	JT9-L100-25-28	Rivet	2x4 mm	4
29	JT9-LM000014	Name Plate, L100-25 with overload		1
30	JT9-L100-25-30	Spur Gear Assembly		2
		Spur Gear		2
		Pinion Gear		2
31	JT9-L100-25-31	Load Sheave		1
31A	JT9-L100-25-31A	C-Clip	6.3x2 mm	1
31B	JT9-L100-25-31B	Needle Bearing HK1208	d12xD16x8 mm	1
32	JT9-L100-25-32	Guide Roller		2
33	JT9-L100-25-33	Stripper		1
34	JT9-L100-25-34	Chain Anchor Plate		1
35	JT9-L100-25-35	Chain Anchor Pin		1
36	JT9-L100-25-36	Split Pin	2x12 mm	1
37	JT9-L100-25-37	Load Chain - specify length	4x12 mm	1
47	JT9-L100-25-47	Snap Ring	18 mm	1
48	JT9-L100-25-48G	Dust Cover		1
	JT9-L100-WT	Warning Tag (not shown)		1

Note: When ordering replacement chain (Index #12, #37), specify length.

Where alternatives are listed, match the model, capacity, lift length, voltage, phase and hook style. Unnumbered component rows belong to the preceding assembly.

mmToolParts
Big Time Experience. Small Town Service. .com