


FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
14	06-82-0164	M5 x 15mm Pan Hd. T-25 Mach. Scr.	(4)
17	06-14-0296	M5 x 50mm Socket Cap Mach. Screw	(4)
47	05-81-0027	M3.5 x 12mm Pan Hd. ST T-10 Screw	(4)
48	----------	Drain Motor/Gearbox	(1)
49	14-20-0088	Main Board PCBA	(1)
50	----------	Mechanical Housing Support	(1)
51	----------	Self-Tapping Insert	(4)
52	06-82-6260	M5 x 35mm Pan Hd. T-25 Machine Scr.	(4)
152	14-02-0025	Foot Pedal Wiring Assembly	(1)
154	----------	LSM B+ and B- Extended Wire Assy.	(1)
155	----------	LSM Battery Wire Assembly	(1)
156	----------	HMI Wire Assembly	(1)
169	----------	M5 x 30mm Pan Hd. ST T-25 Screw	(4)
177	----------	Trigger Wire Assembly (Not Shown)	(1)
186	42-86-0020	Connector Clip	(5)
312	14-50-0028	Drain Drive Motor Assembly	(1)
314	45-76-0027	Drain Gearbox Assembly	(1)
317	14-46-0178	Wiring Service Kit	(1)
320	14-34-0108	Mechanical Housing Kit	(1)

SEE TORQUE SPECS CHART ON PAGE 12




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
51	----------	Self Tapping Inserts	(8)
54	06-82-9217	M5 x 45mm Pan Hd. T-25 Mach. Scr.	(8)
55	----------	Outer Battery Handle Mount-Right	(1)
56	----------	Inner Battery Holder Mount-Right	(1)
57	05-88-0087	M5 x 115mm Pan Hd. T-20 PT Screw	(5)
58	06-82-0029	M5 x 16mm Pan Hd. T-25 ST Screw	(3)
59	----------	Angled Battery Interface-Support	(1)
60	----------	Interface-Right	(1)
61	----------	Front Metal Rails	(2)
63	----------	Pivot Bushing	(2)
64	----------	M3 x 16mm ST Tamperproof Screw	(8)
65	----------	Ejection Spring Holder	(1)
66	----------	Spring	(2)
67	----------	Battery Ejector	(1)
68	----------	Battery Terminal	(1)
69	----------	Pivot Latch	(1)
70	----------	Spring	(2)
71	----------	Torsion Spring	(1)
72	----------	Lever Lockout	(1)
73	----------	Lock Off Lever Pin	(1)
74	----------	Release Lever	(1)
75	----------	Spring	(1)
76	----------	Pivot Latch Spring Holder	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
77	----------	Interface-Left	(1)
78	----------	M3 x 10mmPan Hd. T-10 ST TP Scr.	(3)
79	----------	Coin Cell Pocket	(1)
80	----------	Angled Battery Interface-Cover	(1)
81	----------	M2.6 x 6mm ST FH Phillips Screw	(6)
82	----------	Coin Cell Cover	(1)
83	----------	Anti-Static Seal	(1)
84	----------	Right Inner Battery Handle Mount	(1)
85	----------	Outer Right Battery Holder Mount	(1)
150	14-20-0111	Coin Cell PCBA	(1)
167	----------	Pivot Shaft	(2)
173	----------	Coin Cell Battery (CR32) See local hardware store	(1)
186	42-86-0020	Connector Clip	(1)
322	14-47-0044	Battery Latch Kit	(1)
323	14-46-0181	Battery Ejector Kit	(1)
324	22-09-0016	Coin Cell Cover Kit	(1)
325	43-40-0028	Battery Housing Kit	(1)
326	43-40-0031	Right Battery Frame Cover Kit	(1)
327	42-92-0151	Left Battery Cover Kit	(1)