



Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
1	5140074-41	KNOB ASSY.	1
2	5140074-42	SPRING WASHER	16
3	5140074-43	SCREW W/WASHER	11
4	5140074-44	SCREW	3
5	5140074-45	STEEL BALL	1
6	5140074-46	CORD WRAP	2
7	5140074-47	HEX BOLT	3
8	5140074-48	CLIP	3
9	5140074-49	LOWER BLADE GUARD	1
10	5140074-50	BRUSH HOLDER	1
11	5140101-03	HINGE ASSEMBLY	2
12	5140074-52	HEX BOLT	2
13	5140101-03	HINGE ASSEMBLY	1
14	5140101-03	HINGE ASSEMBLY	1
15	5140074-55	PIN	4
16	5140074-56	SPRING	1
17	5140074-57	SPRING	1
18	5140074-58	ADJ KNOB	1
19	5140074-59	KNOB	1
20	5140074-60	TOOTH WASHER	2
21	5140074-61	FLAT WASHER	2
22	5140074-62	FLAT WASHER	3
23	5140074-63	FLAT WASHER	4
24	5140074-64	SPRING WASHER	1
25	5140074-65	SQUARE NUT	1
26	5140074-66	WING NUT	1
27	5140074-67	HEX NUT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
28	5140074-68	SET SCREW	1
29	5140074-69	SET SCREW	2
30	5140074-70	SCREW	2
31	5140074-71	SCREW	9
32	5140074-72	BEARING COVER	1
33	5140074-73	CLAMP SHOE	2
34	5140074-74	TRUNNION	2
35	5140074-75	DUST COLLECTION PORT	1
36	5140074-76	SCALE	1
37	5140074-77	HINGE	1
38	5140074-78	POINTER	1
39	5140074-79	SPRING PIN	1
40	5140074-80	FLAT WASHER	10
41	5140074-81	HEX NUT	5
42	5140074-82	HEX NUT	5
43	5140074-83	HEX NUT	1
44	5140074-84	HEX SCREW	6
45	5140074-85	HEX SCREW	2
46	5140074-86	SCREW W/WASHER	2
47	5140074-87	HEX WRENCH (3MM)	1
48	5140074-88	HEX SCREW	2
49	5140074-89	SPRING CLIP	3
50	5140074-90	V-BELT	1
51	5140074-91	SCREW W/WASHER	2
52	5140074-92	COPPER WASHER	2
53	5140074-93	WASHER	4
54	5140074-94	FLAT WASHER	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
55	5140074-95	HEX SCREW	1
56	5140074-96	HEX SCREW	2
57	5140074-97	PULLEY	1
58	5140101-03	HINGE ASSEMBLY	1
59	5140074-99	KNOB	2
60	5140075-00	HINGE	1
61	5140075-01	KNOB	3
62	5140075-02	SCREW W/WASHER	12
63	5140075-03	PIN	1
64	5140075-04	HEX SCREW	1
65	5140075-05	SCREW	1
66	5140075-06	BALL BEARING	2
67	5140075-07	BRUSH	1
68	5140075-08	NYLON NUT	1
69	5140075-09	SPRING WASHER	6
70	5140075-10	PLATE	2
71	5140075-11	KEY	1
72	5140075-12	BALL BEARING	2
73	5140075-13	BUSHING STRAIN RELIEF	2
74	5140075-14	RING	2
75	5140075-15	SPRING WASHER	3
76	5140075-16	KNOB	1
77	5140075-17	SCALE	1
78	5140075-18	WARNING LABEL	1
79	5140075-19	WARNING LABEL	1
80	5140075-20	LABEL	1
81	5140075-21	NAME PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
82	5140075-22	SHAFT	1
83	5140101-03	HINGE ASSEMBLY	1
84	5140075-24	INSERT, TABLE	1
85	5140075-25	GUARD	1
86	5140075-26	FLAT WASHER	1
87	5140075-27	BEARING SHAFT	2
88	5140075-28	BLADE GUIDE	4
89	5140075-29	GUIDE	2
90	5140075-30	LOWER GUIDE	1
91	5140075-31	POST SEAT	1
92	5140075-32	BLADE	1
93	5140075-33	GUIDE POST	1
94	5140075-34	WHEEL	2
95	5140075-35	MITER GAUGE ASSY	1
96	5140075-36	KNOB	1
97	5140075-37	RING	2
98	5140075-38	RING	1
99	5140075-39	KEY	2
100	5140075-40	FLAT WASHER	1
101	5140075-41	FLAT WASHER	1
102	5140075-42	FLAT WASHER	1
103	5140075-43	ADJUSTING NUT	2
104	5140075-44	NUT	1
105	5140075-45	SCREW	1
106	5140075-46	SCREW	2
107	5140075-47	SCREW	7
108	5140075-48	HEX SCREW	7

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
109	5140075-49	HEX SCREW	1
110	5140075-50	SWITCH	1
111	5140075-51	BALL BEARING	2
112	5140075-52	CORD SET	1
113	5140075-53	GUARD	1
114	5140075-54	COVER,LOWER	1
115	5140075-55	COVER,UPPER	1
116	5140075-56	LOWER WHEEL	1
117	5140075-57	UPPER WHEEL	1
118	5140075-58	GUARD	1
119	5140075-59	LOWER DOOR	1
120	5140075-60	UPPER DOOR	1
121	5140075-61	UPPER COVER	1
122	5140075-62	TRUNNION BRACKET	1
123	5140075-63	TABLE	1
124	5140075-64	UPPER ARM	1
125	5140075-65	PULLEY	1
126	5140075-66	BASE	1
127	5140075-67	MOTOR	1
129	5140075-69	FLAT WASHER	1
130	5140075-70	SPRING PIN	1
131	5140075-71	SPRING WASHER	2
132	5140075-72	COVER	1
137	5140075-77	TERMINAL	3
138	5140075-78	SCREW	2
139	5140075-79	CAPACITOR	1
140	5140075-80	CORD	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for PCB330BS Type 1

Item Number	Part Number	Description	Qty Required
141	5140075-81	CAPACITOR	1
142	5140075-82	COVER	1
143	5140075-83	UPPER COVER	1
200	5140074-43	SCREW W/WASHER	8
201	5140075-01	KNOB	1
202	5140075-88	CARRIAGE BOLT	16
204	5140075-90	HEX NUT	16
205	5140075-91	PAD	4
206	5140075-92	SPRING WASHER	1
207	5140075-93	HEX NUT	4
208	5140075-94	LABEL	1
209	5140075-95	HEX SCREW	1
210	5140075-96	SELF TAPPING SCREW	2
211	5140075-97	MAGNETIC IRON SET	2
212	5140075-98	RIGHT SIDE COVER	1
213	5140075-99	LEFT SIDE COVER	1
214	5140076-00	DOOR PLATE	1
215	5140076-01	BACK PLATE	1
216	5140076-02	TOP PLATE	1
217	5140076-03	TOOL TRAY	1
846	5140075-89	HARDWARE BAG	1
846	5140076-04	HARDWARE BAG	1
846	5140076-05	HARDWARE BAG	1
846	5140075-87	HARDWARE BAG	1
846	5140075-84	HARDWARE BAG	1
846	5140075-85	HARDWARE BAG	1
846	5140075-86	HARDWARE BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.