





Parts Breakdown

AF503

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	A346-07	EXHAUST VALVE COLLAR, AT638	1
2	A311-OK	O RING 35.5-1.8, AT638	1
3	A312-03	COVER GRIP, AT638	1
4	A200-20	SCREW 5-35, AT638	1
5	I230-NO	EXHAUST COVER, AT638	1
6	A343-29	AIR SEAL, AT638	1
7	B346-06	EXHAUST VALVE ASS'Y, AT638	1
8	A210-25	SPRING, AT638	1
9	A311-OP	O RING 9.8-2.4, AT638	1
10	A311-96	O RING 32-2.5, AT638	2
11	A340-06	HEAD VALVE PISTON, AT638	1
12	A311-OR	O RING 13-3, AT638	1
13	A311-40	O RING 26.59-2.95, AT638	1
14	A311-54	O RING 22.9-2.7, AT638	1
15	A262-10	PISTON HEAD, AF503	1
16	A260-20	DRIVE BLADE, AF503	1
17	A334-02	SLEEVE RETAINER, AT638	1
18	A311-OT	O RING 44.8, 2.6, AT638	1
19	A344-02	SPACER, AT638	1
20	A232-23	CYLINDER, AT638	1
21	A341-21	BUMPER, AT638	1
22	A343-24	GASKET, AT638	1
23	I22N-08	BODY, AT638	1
24	A311-OU	O RING, AT638	1
25	A235-AO	TAIL COVER, AT638	1
26	B236-11	AIR PLUG WITH DUSTER, AT638	1
27	A342-01	NOZZLE, AT638	1
28	A206-29	SPRING PIN 3-24, AT638	1
29	A311-A2	O RING 11-1.05, AF503	1
30	A351-03	UPPER REMOTE HOUSING, AF503	1
31	A210-A0	CONICAL SPRING, AF503	1
32	A311-22	O RING 1.9-1.2, AT638	2
33	A251-16	REMOTE CORE, AF503	1
34	A251-22	REMOTE HOUSING, AF503	1
35	A311-11	O RING 9.8-1.9, AT638	1
36	A210-02	COMPRESSION SPRING, AF503	1
37	A250-04	TRIGGER A, AF503	1
38	A350-04	TRIGGER B, AF503	1
39	A281-22	GUIDE PLATE, AF503	1
40	A210-96	SPRING, AT638	1
41	A280-47	RELEASE CATCH (B), AF503	1
42	A207-23	GUIDE, AF503	1
43	A290-14	SPACER, AF503	1
44	A200-09	SCREW 5-20, AT638	3
45	A200-09	SCREW 5-20, AT638	3
46	A295-30	DRIVER GUIDE COVER, AF503	1
47	A280-46	RELEASE CATCH (A), AF503	1
48	A201-03	SCREW 4-18, AT638	1
49	A294-44	DRIVER GUIDE, AF503	1
50	A206-12	INNER SPRING PIN 2.5-10, AT638	1
51	A275-A1	PUSHER, AF503	1
52	A374-02	SPRING HOLDER, AF503	1
53	A349-04	PAD, AF503	1
54	A276-24	STEEL BAR, AF503	1
55	A204-02	NYLON NUT M5, AT638	1
56	A274-66	MAGAZINE SUPPORT, AF503	1
57	A349-06	BELT HOOK, AT638	1
58	A271-96	LOWER MAG., AF503, T1	1
59	A277-16	CLICK LEVER, AF503	1
60	A210-97	SPRING, AF503	1



Parts Breakdown

AF503

61	A335-01	PLASTIC COVER, AF503	1
62	A206-49	PIN, AF503	1
63	A270-96	UPPER MAG., AF503,T1	1
64	A210-61	COMPRESSION SPRING, AF503	1
65	A278-21	SPACER, AF503	1
66	A203-27	SCREW 4-25, AF503	1
67	A349-05	SCALEBOARD, AF503	1
68	A203-28	SCREW 3-12, AF503	1
69	A312-04	HANDLE GRIP, AT638	1
75	A205-04	E-RING 2.5, AT638	1
76	A206-65	STEP PIN 5-27.3, AT638	1
77	A311-A1	O RING 8-1, AF503	1
78	A311-B9	O RING 24.5-3, AT638	1
79	A311-OQ	O RING 22-1.5, AT638	1
80	A346-06	EXHAUST VALVE SET, AT638	1
81	A205-03	WASHER #5-1.1T, AT638	2
400	1922-A	PROTECTIVE EYE WEAR, AN611	1
401	783201-2	HEX WRENCH 3, AF501	1
402	783202-0	HEX WRENCH 4, JR3000V	1
403	181434-7	OIL SUPPLY 30CC, AF502	1
404	824563-A	PLASTIC TOOL CASE, AT638	1

Toolsandmachinery.com