




Model BHP454**Parts List**

A = Standard Equipment

○ = Circuit Diagram

Fig	Part No.	Description	Q'ty	Unit
1	865306-1	BHP454 NAME PLATE	1	PC.
2	188613-8	HOUSING SET	1	SET
	D10	INC. 23		
3	266130-9	TAPPING SCREW BIND PT 3X16	8	PC.
4	125488-4	SPEED CHANGE LEVER ASS'Y	1	PC.
	C10	233438-6 COMPRESSION SPRING 4	2	PC.
5	419250-0	F/R CHANGE LEVER	1	PC.
6	650573-9	SWITCH	1	PC.
7	631692-0	LIGHT CIRCUIT	1	PC.
8	643812-4	TERMINAL	1	PC.
9	251468-5	- FLAT HEAD SCREW M6X22	1	PC.
A 10	763191-5	KEYLESS DRILL CHUCK 13	1	PC.
11	253798-0	FLAT WASHER 13	1	PC.
12	125487-6	GEAR ASS'Y	1	PC.
13	638613-3	YOKE UNIT	1	PC.
14	619230-8	ARMATURE	1	PC.
15	638614-1	BRUSH HOLDER COMPLETE	1	PC.
16	194427-5	CARBON BRUSH CB-440	1	SET
17	263032-0	RUBBER PIN 4	2	PC.
18	450644-0	REAR COVER	1	PC.
19	266130-9	TAPPING SCREW BIND PT 3X16	2	PC.
20	911006-2	PAN HEAD SCREW M3X8	1	PC.
21	689150-0	HEAT SINK	1	PC.
22	232220-0	LEAF SPRING	2	PC.
23	188613-8	HOUSING SET	1	SET
	D10	INC. 2		
24	266045-0	TAPPING SCREW 4X20	4	PC.
25	424026-2	CUSHION	1	PC.
A A01	122576-8	STOPPER POLE ASS'Y	1	PC.
	C10	286226-0 CAP 20	1	PC.
	C20	322223-3 DEPTH ROD	1	PC.
A A02	122822-9	GRIP ASS'Y	1	PC.
A A03	251314-2	+ SCREW M4X12	2	PC.
A A04	324705-1	HOOK	1	PC.
A A05	419276-2	BIT HOLDER	1	PC.
A A06	784614-0	+/- BIT 2-45	2	PC.
A A07	DC18RA	DC18RA FAST CHARGER	1	
A A08	BL1830	BATTERY BL1830	2	PC.
A A09	450128-8	BATTERY COVER	1	PC.
A A10	824812-5	PLASTIC CARRYING CASE	1	PC.
E01	810300-8	CAUTION LABEL	1	PC.
D01	652045-0	+PAN HEAD SCREW M3.5X5	2	PC.