
CORDLESS PERCUSSION DRIVER DRILL MODEL BHP460SH



IMPORTANT — To assure product SAFETY and RELIABILITY, repairs, maintenance or adjustments should be performed by MAKITA Service Centers or other qualified service organizations. Always use MAKITA replacement parts.

WIRING DIAGRAM




Fig.	Part No.	Qty. Used	Description
2	183245-6	1	HOUSING BUMPER SET (INCL. FIG. 21)
3	183244-8	1	HOUSING SET (INCL. FIG. 20)
4	266130-9	8	TAPPING S. BIND PT 3X16
5	125102-2	1	SPEED CHANGE LEVER ASS'Y (INCL. 2 EA. COMP. SPRING 4 231433-0)
6	416079-5	1	F/R CHANGE LEVER
7	651992-2	1	SWITCH
8	344391-2	2	BIT HOLDER
9	344898-8	1	SUPPORT PLATE
10	643955-2	1	TERMINAL
11	251465-1	1	-FLAT HEAD SCREW M6X32
13	125099-5	1	GEAR ASS'Y (INCL. 1 EA. CHANGE LEVER 417381-9)
14	265999-8	4	TAPPING SCREW 4X25
15	266134-1	3	TAPPING SCREW ST 4X8
16	629755-4	1	DC MOTOR (INCL. 1 EA. SPUR GEAR 20 226361-2, INCL. FIG. 18,19)
17	911006-2	1	PAN HEAD SCREW M3X8
18	191971-3	1	CARBON BRUSH CB-430
19	643954-4	2	HOLDER CAP
20	183244-8	1	HOUSING SET (INCL. FIG. 3)
21	183245-6	1	HOUSING BUMPER SET (INCL. FIG. 2)
23	122575-0	1	GRIP ASS'Y (INC. 1 EA. GRIP 36 CPL. 152521-9, SCREW M5X10 251812-6, HEX. BOLT M8X110 921919-9, HEX. NUT M5 931202-6)

ACCESSORIES

Fig.	Part No.	Qty. Used	Description
400	193065-0	1	KEYLESS DRILL CHUCK 13
401	122576-8	1	STOPPER POLE ASS'Y (INCL. 1 EA. CAP 20 286226-0, DEPTH ROD 122395-2)
402	784614-0	2	BIT 2-45
403	824567-2	1	PLASTIC TOOL CASE (INCL. 2 EA. LATCH 417075-6)
404	193128-2	1	BATTERY B2417 (1.7AH)
405	DC24SA	1	BATTERY CHARGER DC24SA