

79
27
43
62
30
28
82
29
57
12
54
48
3
2
70
71
18
90
37
72
5
24
42
79
15
68
16
56
85
17
18
81
26
41
64
65
50
14
67
44
45
38
21
77
39
80
83
84
22
4
20
19
36
81
69
23
86
49
8
55
9
74
11
51
1
13
46
58
62
52
47
33
63
6
7
10
35
43
190
846
800

Parts List for D51822 Type 3

Item Number	Part Number	Description	Qty Required
1	390140-00	SEAL	1
2	603413-00	SPRING	1
3	390146-00	O-RING	1
4	390147-00	NEGATOR HUB	1
5	647258-00	NOSE	1
6	608611-00	O-RING	1
7	610756-00	PISTON DRIVER ASSY.	1
8	390156-00	O-RING	2
9	390159-00	SEAL	1
10	608615-00	O-RING	1
11	N034172	O-RING	1
12	647261-00	FRAME	1
13	608617-00	O-RING	1
14	612132-00	END CAP	1
15	N016232	CONTACT TRIP	1
16	1000003831	CONTACT TRIP	1
17	326467-00	DETENT	2
18	633359-00	CAP	2
19	390727-00	SHANK LINER	1
20	649201-00	LINER	2
21	606632-00	GUIDE	1
22	645896-00	PUSHER	1
23	610774-00	MAGAZINE CAP	1
24	N000248	GUIDE	1
26	395198-00SV	TRIGGER	1
26	390746-00	TRIGGER	1
27	395091-00	PIN	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D51822 Type 3

Item Number	Part Number	Description	Qty Required
28	617164-00	SPACER	1
29	612149-00	MAGAZINE BRT WASHER	1
30	098197-10	LOCKWASHER	1
33	610753-00	BUTTON	1
35	391789-00	BUMPER	1
36	391795-00	SHANK LINER	1
37	N016446	COVER	1
38	5140040-74	MAGAZINE	1
39	648833-00	BRACKET	1
41	391813-00	SPRING	1
42	391814-00	GROMMET	2
43	627133-00	LABEL	4
44	395195-00	BUSHING	1
45	395196-00	PLUG	1
46	612133-01	DEFLECTOR	1
47	648243-00	GASKET	1
47	608610-00	SEAL	1
48	N009190	COLLAR	1
49	N009191	SPRING RETAINER	1
50	649365-00	GASKET	1
51	646003-00	CYLINDER	1
52	645503-00	TOP CAP	1
54	610777-00	BUMPER	1
55	395215-00	BULKHEAD	1
56	633214-00	ADJUSTER	1
57	650164-00	SCREW	2
58	650162-00	SCREW	3

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D51822 Type 3

Item Number	Part Number	Description	Qty Required
62	650165-00	SCREW	5
63	650159-00	SCREW	1
64	650155-00	SPIRAL PIN	1
65	650156-00	SPIRAL PIN	2
67	650163-00	SCREW	3
68	5140095-73	TRIGGER VALVE KIT	1
69	640783-00	SPACER	1
70	603561-00	BAND	1
71	617161-00	O-RING	1
72	390735-00	SPRING	1
74	606640-00	O-RING	1
77	N016427	LABEL	1
79	626181-00	LABEL	2
80	650161-00	SCREW	3
81	330021-01	NUT,STOP	4
82	617165-00	WEAR PLATE	1
83	N013208	LABEL	1
84	647245-00	WARNING LABEL	1
85	633216-00	DETENT BUSHING	2
86	650160-00	SCREW	1
90	N013927	INSTRUCTION LABEL	1
190	629042-00	SAFETY GLASSES	1
800	429995-00	GREASE	1
846	606130-01	BUMPER	1
846	606131-00SV	MAGAZINE SPRING	1
846	5140112-77	O-RING KIT	1
846	609993-00	TRIGGER	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D51822 Type 3

Item Number	Part Number	Description	Qty Required
846	606125-00	PISTON DRIVER ASSY.	1
846	606132-00	TRIGGER VALVE ASY	1
846	606134-00	TRIGGER	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.