4
1
6
5
11
7
8
35
40
16
15
17
18
19
20
14
12
13
1
9
23
3
2
10
861
871
866
867
800

Parts List for DC727KA Type 1

Item Number	Part Number	Description	Qty Required
1	620787-00	CLAMSHELL SET	1
2	148354-03	BIT CLIP	1
3	607918-41	SCREWDRIVER BIT	1
4	395657-00	ID LABEL	1
5	330075-65	KEYLESS CHUCK	1
6	605256-01	SCREW	1
7	634728-00	FWD/REV BUTTON	1
7	623997-00	FWD/REV BUTTON	1
8	392086-01SV	SHIFTER	1
9	152274-26	DC VSR SWITCH	1
10	682211-00	SCREW,TORX	8
11	618335-00	ADJUST COLLAR	1
12	326467-00	DETENT	1
13	397156-00SV	MOTOR & PINION	1
14	623331-00SV	TRANSM.&CLUTCH	1
15	392095-00	SPINDLE ASSY.	1
16	386690-00	BALL	6
17	397303-00	CLUTCH PLATE	1
18	391912-01	CLUTCH SPRING	1
19	391911-00	ADJUSTING NUT	1
20	798959-00	CLIP,BEARING	1
23	620806-00	NAMEPLATE	1
35	391896-00	SHIFTER WIRE	1
40	392094-00	PIN	2
800	284778-00	GREASE,MOLYKOTE	1
861	637475-00	LATCH ASSEMBLY	2
861	380865-02	KIT,HANDLE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC727KA Type 1

Item Number	Part Number	Description	Qty Required
861	652211-00	KITBOX	1
866	397745-01SV	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.