



Parts List for DC927KL Type 1

Item Number	Part Number	Description	Qty Required
1	647555-00	CLAMSHELL SET	1
2	652246-00	IDENT. LABEL	1
3	647558-00	REVERSE LEVER	1
4	152274-25SV	VSR SWITCH	1
5	649056-01SV	MOTOR & PINION ASSY	1
6	649026-00SV	TRANSMISSION ASSY.	1
7	682211-00	SCREW,TORX	7
8	647566-01SV	CHUCK & SPINDLE ASSY	1
9	330019-52	SCREW PLASTITE	4
10	651872-00	LEADWIRE ASSY.	1
11	651873-00	LEADWIRE ASSY.	1
12	148354-03	BIT CLIP	1
13	N113656	KEYLESS CHUCK	1
14	603754-01	BRUSH BOX	2
16	638117-00	DETENT SPRING	1
17	647561-00	NAMEPLATE	1
20	650676-00	WARNING LABEL (SPA)	1
21	330019-00	SCREW	3
22	649054-00	SHIFT COLLAR	1
23	649055-00	COLLAR	1
24	649057-00	CAP	1
25	649053-00	COLLAR,CLUTCH	1
26	395460-00	DETENT SPRING	1
27	647567-01	SPINDLE HOUSING ASSY	1
28	638427-00	SPINDLE & BRG.	1
29	394546-00	SPRING	1
30	399059-00	CAM RETURN SPRING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC927KL Type 1

Item Number	Part Number	Description	Qty Required
31	634729-00	DETENT SPRING	1
32	394545-00	CAM RING	1
33	638072-00	FIXED RATCHET	1
36	646594-00	SIDE HANDLE	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
836	559662-99	MANDREL	1
836	559697-99	INSERT	1
836	233804-40	CHUCK REMOVAL FIXTURE	1
861	660141-00	KITBOX	1
866	DC9180	18V BATTERY PACK	2
867	650912-00	BATTERY CAP	1
871	DC9310	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicen.com for current parts information.