862
871
866
856
DATE CODE
2
41
42
10
24
31
23
1
5
18
14
36
32
35
22
4
34
9
20
33
1
8
21
15
7
43
16
2
17
21
6
40
19

# Parts List for DCS310S1 Type 1

| Item Number | Part Number | Description | Qty Required |
|---|---|---|---|
| 1 | N127602 | HOUSING ASSEMBLY | 1 |
| 2 | N127571 | HANDLE HOUSING | 1 |
| 4 | N131523 | SHAFT/BRG.ASSY | 1 |
| 5 | N131525 | SWITCH,VAR.SPD. | 1 |
| 6 | N096581 | SHOE ASSEMBLY | 1 |
| 7 | N098006 | LEVER ASSEMBLY | 1 |
| 8 | N101648 | SUPPORT BRACKET | 1 |
| 9 | N114801 | LED,COATED | 1 |
| 10 | N131526 | LOCK,PIVOT | 1 |
| 14 | N098461 | LOCK BAR | 1 |
| 15 | N116071 | RUBBER SEAL | 1 |
| 16 | N116072 | RUBBER SEAL | 1 |
| 17 | N116073 | SEAL | 2 |
| 18 | N015397 | PLUG | 2 |
| 19 | 330065-31 | SCREW | 2 |
| 20 | N086775 | SCREW | 2 |
| 21 | 682211-00 | SCREW,TORX | 14 |
| 22 | N131521 | DRIVE BEARING | 1 |
| 23 | N031603 | RUBBER PLUG | 2 |
| 24 | N108470 | RETAINER RING | 1 |
| 31 | N131518 | MOTOR ASSEMBLY | 1 |
| 32 | N131520 | GEAR CASE ASSY | 1 |
| 33 | N131522 | SHAFT & CLAMP ASSY | 1 |
| 34 | N131519 | GEAR ASSEMBLY | 1 |
| 35 | 098091-10 | SCREW | 3 |
| 36 | 330045-43 | SCREW,TAPTITE | 2 |
| 40 | N143836 | NAMEPLATE | 1 |

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

# Parts List for DCS310S1 Type 1

| Item Number | Part Number | Description | Qty Required |
|---|---|---|---|
| 41 | N143837 | WARNING LABEL | 1 |
| 42 | N143839 | ID LABEL | 1 |
| 43 | N143838 | LABEL | 1 |
| 856 | N065013-32 | RECIP. BLADE | 1 |
| 856 | DW4810 | 4IN 18TPI STRAIG BK BLADE | 1 |
| 862 | N131926 | TOOL BAG | 1 |
| 866 | DCB120 | BATTERY PACK | 1 |
| 871 | DCB100 | CHARGER | 1 |

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.