

98
9
7
8
5
10
21
4
22
11
18
19
23
15
20
821
16
44
3
24
6
17
23
2
90
13
826
12
25
26
29
27
14
28
1
35
30
88
34
92
57
42
36
43
18
37
45
38
41
58
56
53
52
40
47
54
39
18
31
91
83
51
55
89
23
70
48
96
856
857
861
836
50
60
61
62
49
63
65
65
64
65
67
66
93
59
69
70
68
84
85

Parts List for DW621-220 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	327429-10	FIELD	1
3	323132-00	SWITCH,ON/OFF	1
4	326297-00	MODULE,ELECTRON	1
5	000000-00	No Longer Available	1
6	580017-00	BRUSH	2
7	330065-13	SCREW	2
8	326259-01	CAP,END	2
9	327434-01	ADAPTOR	1
10	326287-00	CAP	1
11	326268-00	BELLOWS	1
12	326283-00	SPRING	1
13	326279-00	CLIP	1
14	326607-00	CLIP	1
15	326933-01	HOLDER,CHOKE	2
16	326667-00	SPRING,BRUSH	2
17	578774-00	IDENT. LABEL	1
18	324006-00	SCREW	9
19	326251-00	MAGNET	1
20	328252-02	HOUSING,MOTOR	1
21	770235	CORD PROTECTOR	1
22	821070	CORD CLAMP	1
23	330065-06	SCREW	6
24	326258-01	COVER,SWITCH	1
25	330065-10	SCREW	2
26	326845-00	WASHER,SPRING	1
27	329016-00	GUIDE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW621-220 Type 1

Item Number	Part Number	Description	Qty Required
28	323395-13	SPRING	1
29	605040-63	BEARING	1
30	326604-00	BAFFLE,FAN	1
31	326616-03	SPNDLE.LOCK ASY	1
34	327136-00	SCREW	3
35	326600-00	ADJUSTER	1
36	326265-01	SCALE	1
37	321118-00	WASHER	1
38	323395-14	SPRING	1
39	329027-49	RACK & PINION	1
40	326602-00	INSERT	1
41	328254-01	HOUSING,LOWER	1
42	326285-00	CLAMP	1
43	570936-01	BALL BEARING	1
44	330065-04	SCREW	2
45	326606-00	GUIDE	1
47	326673-01	RING,LOCKING	1
48	326286-03	COLLET & NUT	1
49	326273-00	GUARD,DUST	1
50	326599-01	CAP	1
51	326598-01	HANDLE ASY.HALF	1
52	323395-10	SPRING	1
53	326601-00	ACTUATOR	1
54	326252-01	TRIGGER	1
55	326256-00	LEVER	1
56	949726-05	NUT	1
57	326573-01	SCREW,WING	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW621-220 Type 1

Item Number	Part Number	Description	Qty Required
58	868082-00	SPRING	1
59	328253-00	BASEPLATE	1
60	326610-00	SCREW	1
61	327012-00	WASHER,SPRING	1
62	000000-00	No Longer Available	1
63	942931-01	SCREW	1
64	942931-02	SCREW	1
65	330015-04	NUT,HEX	3
66	326662-00	TURRET	1
67	720664-00	BALL	1
68	326270-00	BASE,SUB	1
69	324821-00	CIRCLIP	1
70	945121-00	SCREW,M4X0.7	7
83	761289-00	WRENCH (22MM)	1
84	329120-01	ADAPTOR	1
85	911141-00	SCREW	2
88	326300-00	KNOB	1
89	326313-01	HANDLE,CVR.HALF	1
90	911026-00	SCREW	4
91	323395-22	SPRING	1
92	323711-26	RING,O	1
93	868082-00	SPRING	1
96	326286-04	COLLET & NUT	1
98	328592-00	ADAPTOR,VACUUM	1
821	000000-00	No Longer Available	1
826	490086-00	WARNING LABEL	1
836	559585-98	GUIDE	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW621-220 Type 1

Item Number	Part Number	Description	Qty Required
836	559585-97	PIN	1
836	559585-96	GUIDE	1
856	DW6913	ROUTER EDGE GUIDE	1
857	000000-00	No Longer Available	1
861	578772-53	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.
Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.