





Parts Breakdown

HP1500

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	265995-6 266121-0	TAPPING SCREW 4X18, BO4556K TAPPING SCREW PF4X18,9523NB	8
2	858216-9	NAME PLATE, HP1500	1
3	182841-7 182730-6	HOUSING SET, HP1501 HOUSING SET,HP1500	1
4	415453-4	CHANGE BUTTON, HP1501	2
6	651986-7 651987-5 651935-4	SWITCH, 6410 SWITCH, HP2040 SWITCH, HP2030-T1	1
9	CB407 195007-0 191927-6	CARBON BRUSH SET, 195007-0 CARBON BRUSH SET, 195007-0 CARBON BRUSH SET CB-407, BO5030K	1
10	643936-6 643923-5	BRUSH HOLDER, 6821 BRUSH HOLDER, HR2410	2
11	921923-8 921919-9	HEX. BOLT M8 X 120, HP2050F BOLT M8X10, HP2030	1
12	415485-1	GRIP BASE, HP2030	1
13	152489-9	GRIP 36, HR2410	1
16	192541-1 763142-8 763115-1 763114-3	DRILL CHUCK S13, HP1620F DRILL CHUCK S13, HP1620F DRILL CHUCK DRILL CHUCK S13, HP2040	1
17	323757-9 322900-7	SPINDLE, HP1500 SPINDLE, HP1501	1
18	233091-8	COMP. SPRING 16, HP2030	1
19	211201-7	B. BEARING 6002LLB, 6510LVR	1
20	961055-9	RETAINING RING S-15, 5007F	1
21	226423-6	HELICAL GEAR 41, HP1501	1
22	216001-0 216002-8	STEEL BALL 3.5, LXDT08 STEEL BALL 4.8, WT01W	1
23	344419-6 344112-2	CHANGE PLATE, HP1501 CHANGE PLATE, HP1500	1
24	232134-3	LEAF SPRING, HP1501	1
25	152529-3 152473-4	CAM HOLDER CPL.,HP1501 CAM HOLDER CPL.,HP1500	1
26	211028-5	B. BEARING 627LB, 6510LVR	1
27	633301-7	FIELD 115V, HP1501	1
28	517106-2	ARMATURE ASS'Y 115V, HP1501	1
29	211033-2	B. BEARING 608LB, 5007F	1
30	262528-8	SLEEVE 7, HP1501	1
31	265995-6 266121-0	TAPPING SCREW 4X18, BO4556K TAPPING SCREW PF4X18,9523NB	2
32	687063-9	STRAIN RELIEF, 4323K	1
33	682549-8	CORD GUARD 8, HP1640	1
34	664881-2	CORD	1
35	819063-3	MAKITA LABEL, DA3010F	1
36	182841-7 182730-6	HOUSING SET, HP1501 HOUSING SET,HP1500	1
37	256251-5 763440-0 763430-3 415486-9	PIN 4, HP2050F CHUCK KEY S13, HP1640 CHUCK KEY S13, HP2050F STOPPER POLE, HP2030	1