







Parts Breakdown

LS1020

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	163100-8	SHAFT LOCK, LS1020	1
2	411466-3	BAFFLE PLATE, LS1020	1
3	213459-4	O RING 32, 5007F	1
4	211106-1	B. BEARING 6201LLB, 9227C	1
	211144-3	BALL BEARING 6201LLB,9035	
	211106-1	B. BEARING 6201LLB, 9227C	
5	241514-2	FAN 92, LS1440	1
6	514816-2	ARMATURE ASS'Y 115V, LS1030	1
7	681623-9	INS. WASHER, 2012NB	1
8	211068-3	B. BEARING 6200LB, GA7911	1
9	911290-9	P.H. SCREW M5X65, GA7911	2
10	263002-9	RUBBER PIN 4, 5007MG	1
11	526006-5	FIELD, LS1440, T2	1
	524776-0	N/A	
12	157742-8	MOTOR HOUSING, LS1020	1
13	855945-5	NAME PLATE, LS1020	1
14	953106-2	RIVET 0-5, HM1500	4
16	251335-4	P.H. SCREW M5X80, LS1020	4
17	911158-9	P.H. SCREW M4X30, 9045B	3
18	CB154	CARBON BRUSH SET, 194986-9	1
	194986-9	CARBON BRUSH SET, 194986-9	
	181047-4	CARBON BRUSH SET 154,5402A	
19	643650-4	BRUSH HOLDER CAP, 5007F	2
20	911128-8	P.H. SCREW M4X16, LXPk01	2
21	411467-1	CLAMP COVER, LS1020	1
22	911133-5	P.H. SCREW M4X18, N9501B	2
23	687001-1	STRAIN RELIEF, 6013BR	1
25	410875-3	HANDLE COVER, LS1020	1
26	911101-8	P.H. SCREW M4X6, LS1020	1
27	651153-4	SWITCH, LS1440	1
	651135-6	SWITCH, LS1020	
28	154377-6	CLAMP BASE, LS1440	1
29	682505-8	CORD GUARD, 5007F	1
30	664265-4	CORD (2X16X8;SJ), 5007NBA	1
31	251953-8	SCREW M10X70, LS1020	1
32	941252-3	F. WASHER 10, LS1020	1
33	931501-6	HEX NUT M10, LS1020	1
34	421328-7	CUSHION, LS1020	1
35	251399-8	P.H.SCREW M5X22, LS1020	1
36	911121-2	P.H. SCREW M4X14, 9217SPC	2
37	254203-0	KEY 4, 5201NA	1
38	912327-5	C.S.H. SCREW M6X18, LS1020	2
39	342968-7	BAND HOLDER, LS1020	2
40	410723-6	CARRYING BAND, LS1020	1
41	343465-6	GUIDE ARM, LS1020	1
42	253022-1	F. WASHER 8, 5277NB	1
43	251331-2	P.H. SCREW M6, LS1020	1
44	253715-0	F. WASHER 6, NHP1310	1
45	257022-3	RING 16, LS1013	1
46	251331-2	P.H. SCREW M6, LS1020	1
47	923901-4	C.S.N. BOLT M5X8, LS1020	1
48	342971-8	PLATE, LS1020	1
49	231933-0	SPRING 26, LS1020	1
50	265324-3	H.F.H. BOLT M8X12, LS1016L	1
51	414032-5	SAFETY COVER, LS1020	1
52	942101-7	SPRING WASHER 5, 9005B	1
53	931202-6	HEX NUT M5, LS1016L	1
54	151287-8	BLADE CASE,LS1020 (TYPE 2)	1



Parts Breakdown

LS1020

55	251637-8	H. BOLT M8X20, LS1020	1
56	224118-5	OUTER FLANGE, LS1020	1
57	224241-6	INNER FLANGE 55, LS1020	1
58	911231-5	P.H. SCREW M5X20, HR4002	4
59	285660-1	BEARING RETAINER 71, LS1020	1
60	321922-4	SPINDLE, LS1020	1
61	253328-7	T. WASHER 17, LS1020	1
62	211256-2	B. BEARING 6203LLB, GA7001L	1
63	312982-7	HOUSING W/O BEARING, LS1020	1
64	221712-4	HELICAL GEAR 41, LS1020	1
65	961057-5	RETAINING RING S-17, LS1016L	1
66	212101-4	N. BEARING 1210, LS1020	1
67	157856-3	GEAR HOUSING, LS1020 (TYPE 2)	1
68	921541-2	HEX BOLT M10X25, 2414	4
69	316067-1	GUIDE FENCE, LS1020 (TYPE 2)	1
70	163271-1	SUPPORTER, LS1020	1
71	911321-4	P.H. SCREW M6X16, 5402A	1
72	251954-6	SET SCREW M10, LS1020	1
73	251698-8	H. BOLT M16, LS1020	1
74	253771-0	F. WASHER 16, LS1011	1
75	154354-8	ARM COMPLETE, LS1020	1
76	231530-2	TOR. SPRING 32, LS1020	1
77	341511-9	STOPPER, LS1020	1
78	253948-7	W. WASHER 8, LS1016L	1
79	253309-1	T. WASHER 8, LS1020	1
80	251267-5	P.H. SCREW M6, LS1016L	1
81	253771-0	F. WASHER 16, LS1011	1
82	252044-8	HEX LOCK NUT M16-24, LS1020	1
83	414236-9	CHIP DEFLECTOR, LS1020 (T2)	1
84	410704-0	SLOT INSERT, LS1020	1
85	312511-6	SET PLATE, LS1020	1
86	191550-7	HOLDER SET, LS1000, LS1020	1
	321790-5	HOLDER	
87	251804-5	SCREW M6X12, LS1020	1
88	151221-8	BASE COMPLETE, LS1020	1
89	341912-1	NUT HOLDER, LS1020	1
90	911216-1	P.H. SCREW M5X14, N9501B	1
91	342967-9	SET PLATE, LS1020	1
92	341911-3	PROTECTOR, LS1020	2
93	321490-7	RELEASE NUT (R), LS1020	1
94	321491-5	RELEASE NUT (L), LS1020	1
95	151201-4	VICE ARM CPL., LS711DWBEK	1
	151202-2	VICE ARM, LS1020, T1	
96	271272-6	VICE KNOB, LS1000	1
97	253744-3	F. WASHER 12, LS1016L	1
98	315891-9	VICE PLATE, LS1020, LS1440	1
99	253047-5	F. WASHER 6, LXSM01	1
100	911317-5	P.H. SCREW M6X14, LS1000, LS1440	1
101	911108-4	P.H. SCREW M4X8, LS1013	2
102	816173-7	INDICATION LABEL, LS1020	1
103	342823-3	PLATE, LS1020	1
104	273481-3	HANDLE, LS1020	1
105	342824-1	LATCH SPRING, LS1020	1
106	911246-2	P.H. SCREW M5X28, 6013BR	1
107	321789-0	LATCH PIN, LS1020	1
108	921441-6	HEX BOLT M8X25, LS1020	2
109	232091-5	LEAF STAY, LS1020	1
110	311772-5	TURNING STAY, LS1020	1
111	924311-8	THUMB SCREW M6X12, 4110C	2
112	191550-7	HOLDER SET, LS1000, LS1020	1
	321790-5	HOLDER	



Parts Breakdown

LS1020

113	922457-4	H.S.H. BOLT M8X35, LS1020	2
114	942201-3	SPRING WASHER 8, 2414NB	2
115	311788-0	TURN TABLE, LS1020	1
116	951113-9	SPRING PIN 4-18, LS1020	2
117	343492-3	BLADE STOPPER, LS1020	2
118	911206-4	P.H. SCREW M5X10, 1806B	2
119	253139-0	F. WASHER 8, 6510LVR	1
	782232-8	BOX WRENCH 13, LS1016	1
	782212-4	SOCKET WRENCH 13, LS1011	
	122351-2	DUST BAG, LS1030	1
	410602-8	FASTENER, LS1016L	1
	122567-9	VICE ASS'Y., LS711DWBEK	1
	122568-7	H. VISE ASS'Y., LS1020-T1	
	134452-4	N/A	1
	321140-4	TUBE HOLDER	1
	911106-8	P.H. SCREW M4X8, NHP1310	1
	411477-8	STOPPER, LS1020	1
	411478-6	SWITCH BUTTON, LS1011	1