







Parts Breakdown

LS1211

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	251667-9	H. BOLT M8X75, LS1030	1
2	262511-5	RUBBER SLEEVE 6, LS1030	1
3	415207-9	ELBOW, LS1211	1
4	213558-2	O RING 42, LS1211	1
5	256687-8	PIN 8, LS1211	1
6	911113-1	P.H. SCREW M4X10, LS1016L	1
7	344045-1	STOPPER ARM PLATE, LS1211	1
8	317176-9	STOPPER ARM, LS1212	1
	316471-4	STOPPER ARM, LS1211	
9	262001-8	RING 5, LS1016L	1
10	265717-4	SCREW M6X43, LS1016L	1
11	681633-6	INSULATION WASHER, LS1211	1
12	210042-8	BALL BEARING 629LLB, LXDG01	1
	211056-0	B. BEARING 629LLB, 4101RH	
13	415213-4	BAFFLE PLATE, LS1211	1
14	636021-2	FIELD, LS1211	1
15	911363-8	P.H. SCREW M6X40, LS1211	4
16	CB203	CARBON BRUSH SET, 194991-6	1
	194991-6	CARBON BRUSH SET, 194991-6	
	191953-5	CARBON BRUSH SET CB-203, LS1211	
17	643700-5	BRUSH HOLDER CAP, GA7021	2
18	857306-5	NAME PLATE, LS1211	1
19	159618-5	MOTOR HOUSING CPL., LS1211	1
20	911944-8	P.H.SCREW M5X80, LS1211	2
21	516546-1	ARMATURE ASS'Y 115V, LS1211	1
22	241514-2	FAN 92, LS1440	1
23	911223-4	P.H. SCREW M5X16, 5007MG	4
24	285829-7	BEARING RETAINER 92, LS1211	1
25	253853-8	F. WASHER 15, LS1211	1
26	211206-7	B. BEARING 6202LLB, 5007F	1
27	961055-9	RETAINING RING S-15, 5007F	1
28	231928-3	RING SPRING 8, LS1016L	1
29	256633-1	PIN 6, LS1016L	1
30	231240-1	COMP. SPRING 7, LS1016L	1
31	188160-9	BLADE CASE SET, LS1211	1
	151420-2	BLADE CASE CPL., LS1211	
	151424-4	BLADE CASE CPL., LS1211	
	151399-7	BLADE CASE CPL.,LS1211	
32	961018-5	STOP RING E-5, LS1016L	1
33	253804-1	F. WASHER 6, LS1016L	1
34	257163-5	RING 6, LS1016L	1
35	343997-3	LINK PLATE, LS1211	1
36	819064-1	MAKITA MARK, 5402NA	1
37	257163-5	RING 6, LS1016L	1
38	253804-1	F. WASHER 6, LS1016L	1
39	922331-6	H.S.H. BOLT M6X20, LS1016L	1
40	911113-1	P.H. SCREW M4X10, LS1016L	1
41	687042-7	STRAIN RELIEF, 2711	1
42	911113-1	P.H. SCREW M4X10, LS1016L	2
43	344039-6	F.BELLOWS COVER, LS1211	1
44	152984-9	SLIDE PIPE CPLT., LS1211	1
	152474-2	N/A	
45	265406-1	H.BOLT M10X130, LS1211	1
46	941251-5	F. WASHER 10, LS1030	1
47	331428-4	PIPE, 2414NB	1
48	921451-3	HEX BOLT M8X30, LS1011	1
49	322629-5	STOPPER PIN, LS1216	1
50	213011-8	O RING 7, HR2511,LS1214FL	1



Parts Breakdown

LS1211

51	271601-3	KNOB 20, LS1016L	1
52	941251-5	F. WASHER 10, LS1030	1
53	252130-5	HEX LOCK NUT M10, LS1016L	1
54	316470-6	SPRING HOLDER, LS1211	1
55	233074-8	COMP. SPRING 34, LS1211	1
56	265925-7	TAPPING SCREW BT4X20, 6201DW	4
57	911233-1	P.H. SCREW M5X20, TW1000	2
58	182597-2	HANDLE SET, LS1211	1
59	265995-6	TAPPING SCREW 4X18, BO4556K	2
60	687052-4	STRAIN RELIEF, 5007F	1
61	682505-8	CORD GUARD, 5007F	1
62	664463-0	CORD (2X14X8 SJ), 5007F	1
63	265925-7	TAPPING SCREW BT4X20, 6201DW	1
64	411478-6	SWITCH BUTTON, LS1011	1
65	182597-2	HANDLE SET, LS1211	1
66	414546-4	CAM, LS1011	1
67	414547-2	LOCK-OFF LEVER, LS1011	1
68	231457-6	COMP. SPRING 3, HR2400	1
70	651923-1	SWITCH, LS1040	1
71	414157-5	SWITCH LEVER, LS1030	1
73	211031-6	BALL BEARING 608LLB, 9227C	1
74	226707-2	SPIRAL BEVEL GEAR 39, LS1211	1
75	316473-0	HOUSING W/O BEARING, LS1211	1
76	211278-2	BALL BEARING 6203DDW, GA7021	1
	211256-2	B. BEARING 6203LLB, GA7001L	
77	322625-3	SPINDLE, LS1221	1
78	285828-9	BEARING RETAINER 66, LS1211	1
79	911223-4	P.H. SCREW M5X16, 5007MG	2
80	224333-1	FLANGE 53, LS1040	1
	224279-1	FLANGE 55, LS1011	
81	257060-5	RING 15.88,LS1013	1
82	224333-1	FLANGE 53, LS1040	1
	224279-1	FLANGE 55, LS1011	
83	265405-3	H.F.H. BOLT M10X20, LS1016L	1
84	192675-0	N/A	1
	344037-0	CENTER PLATE, LS1211,T1	
85	344038-8	CENTER COVER, LS1211	1
86	265008-3	.SCREW M5, LS1011	1
	265985-9	HEX.SOCKET HEAD BOLT M6, LS1016L	
	265008-3	.SCREW M5, LS1011	
87	231613-8	T. SPRING 45, LS1211	1
88	192675-0	N/A	1
	415217-6	SAFETY COVER, LS1211,T1	
89	253977-0	F. WASHER 6, LS1011	1
90	911223-4	P.H. SCREW M5X16, 5007MG	1
91	265324-3	H.F.H. BOLT M8X12, LS1016L	1
92	921451-3	HEX BOLT M8X30, LS1011	4
93	316480-3	GUIDE RULE, LS1211	1
94	251887-5	SCREW M6X10, LS1016L	1
95	219011-6	N/A	1
96	416888-2	REAR ARM COVER, LS1211	1
	415212-6	REAR ARM COVER, LS1211	
97	415210-0	BELLOWS, LS1211	1
98	911113-1	P.H. SCREW M4X10, LS1016L	2
99	344042-7	REAR BELLOWS PLATE, LS1211	1
100	344757-6	REAR BELLOWS COVER, LS1211	1
	344040-1	REAR BELLOWS COVER, LS1211	
101	687042-7	STRAIN RELIEF, 2711	1
102	911113-1	P.H. SCREW M4X10, LS1016L	2
104	232075-3	LEAF SPRING, LS1016L	1
105	251897-2	SCREW M6X33, LS1211	1



Parts Breakdown

LS1211

106	262001-8	RING 5, LS1016L	1
107	344041-9	F. BELLOWS PLATE, LS1211	1
108	416887-4	FRONT ARM COVER, LS1211	1
	415211-8	FRONT ARM COVER, LS1211	
109	265925-7	TAPPING SCREW BT4X20, 6201DW	2
110	415210-0	BELLOWS, LS1211	1
111	911113-1	P.H. SCREW M4X10, LS1016L	1
112	343902-0	POINTER, LS1211	1
113	265455-8	HEX BOLT M8X28, LS1212	1
115	252105-4	HEX LOCK NUT M8-13, LS1040	1
116	253852-0	F. WASHER 8, LS1211	1
117	150444-5	TURN BASE CPL., LS1211	1
118	416886-6	KERF BOARD, LS1211,LS1212	1
	415209-5	KERF BOARD, LS1013,LS1013F	
119	251314-2	SCREW M4X12, LXPH03	2
121	416886-6	KERF BOARD, LS1211,LS1212	1
	415209-5	KERF BOARD, LS1013,LS1013F	
122	343678-9	INDICATION PLATE, LS1016L	1
123	911113-1	P.H. SCREW M4X10, LS1016L	1
124	344043-5	LOCK PLATE, LS1211	1
125	911213-7	P.H. SCREW M5X12, LS1040	2
126	150445-3	FRONT COVER CPL., LS1211	1
127	911233-1	P.H. SCREW M5X20, TW1000	2
128	273637-8	GRIP 34, LS1211	1
129	216004-4	STEEL BALL 7.9, HR3851	1
130	231038-6	COMP. SPRING 5.5, LS1011	1
131	286212-1	CAP 20, 2705	2
132	151505-4	BASE COMPLETE, LS1211	1
	151400-8	BASE CPL., LS1211	
133	251887-5	SCREW M6X10, LS1016L	2
134	911233-1	P.H. SCREW M5X20, TW1000	1
135	322601-7	HOLDER, LS1211	1
136	344044-3	SLIDE PLATE, LS1211	3
137	256752-3	PIN 6, LS1211	1
138	265455-8	HEX BOLT M8X28, LS1212	1
139	322628-7	LOCK BOLT M10, LS1211	1
140	257656-2	SLEEVE 17, LS1211	1
141	231615-4	TORSION SPRING 30, LS1211	1
142	961054-1	RETAINING RING S-14, 6302	1
143	316472-2	STOPPER, LS1211	1
144	231614-6	TORSION SPRING 15, LS1211	1
145	125093-7	ARM ASSEMBLY	1
	125034-3	ARM ASS'Y, LS1211	
146	415208-7	RELEASE BUTTON, LS1016L	1
147	286236-7	CAP 16, LXSL01	2
148	911213-7	P.H. SCREW M5X12, LS1040	1
149	316488-7	LEVER HOLDER, LS1211	1
150	263002-9	RUBBER PIN 4, 5007MG	1
151	252075-7	HEX NUT M10-17, LS1211	1
152	267052-6	F. WASHER 10, UH401DW	1
153	216414-5	T. NEEDLE CAGE 1024, LS1211	1
154	267052-6	F. WASHER 10, UH401DW	1
155	224333-1	FLANGE 53, LS1040	1
	344046-9	LOCK FLANGE, LS1211, T1	
156	322630-0	LEVER ROD 10, LS1211	1
157	213062-1	O RING 9, GA7021	1
158	421550-6	RUBBER RING 35, LS1211	1
	421493-2	O RING,LS1211, T1	
	251887-5	SCREW M6X10, LS1016L	1
	322313-2	WISE ROD, LS1030	1
	271286-5	KNOB 40, LS1011	1



Parts Breakdown

LS1211

122536-0	VICE ASS'Y, LS1040F	1
122468-1	VICE ASS'Y	
253804-1	F. WASHER 6, LS1016L	1
343651-9	VICE PLATE, LS1016L	1
251370-2	PAN HEAD SCREW, 5007MG	1
265917-6	ADJUST BOLT M8X42, LS1211	2
122446-1	HOLDER ASSEMBLY, LS1211	1
316418-8	HOLDER	
251887-5	SCREW M6X10, LS1016L	2
322602-5	HOLDER, LS1211	2
411478-6	SWITCH BUTTON, LS1011	2
762001-3	TRIANGLE RULE, LS1016L	1
782232-8	BOX WRENCH 13, LS1016	1
782212-4	SOCKET WRENCH 13, LS1011	
410602-8	FASTENER, LS1016L	1
122469-9	DUST BAG ASS'Y, LS1211	1