







Parts Breakdown

LS1212

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	911373-5	P.H. SCREW M6X50, LS1013	4
2	159962-0	MOTOR HOUSING COMPLETE, LS1013	1
3	265995-6	TAPPING SCREW 4X18, BO4556K	2
4	416075-3	REAR COVER, LS1013	1
5	631237-4	CONTROLLER, LS1214FL	1
6	265995-6	TAPPING SCREW 4X18, BO4556K	1
7	CB154	CARBON BRUSH SET, 194986-9	1
	194986-9	CARBON BRUSH SET, 194986-9	
	181047-4	CARBON BRUSH SET 154,5402A	
8	643650-4	BRUSH HOLDER CAP, 5007F	2
9	858579-3	N/A	1
10	596156-0	FIELD ASS'Y 115V, LS1212	1
11	266059-9	T. SCREW, FLANGE 5X75,2414B	2
12	911223-4	P.H. SCREW M5X16, 5007MG	2
13	233187-5	COMPRESSION SPRING 34, LS1212	1
14	316470-6	SPRING HOLDER, LS1211	1
15	257163-5	RING 6, LS1016L	1
16	253804-1	F. WASHER 6, LS1016L	1
17	922331-6	H.S.H. BOLT M6X20, LS1016L	1
18	344472-2	LINK PLATE, LS1212	1
19	257163-5	RING 6, LS1016L	1
20	253804-1	F. WASHER 6, LS1016L	1
21	961018-5	STOP RING E-5, LS1016L	1
22	231240-1	COMP. SPRING 7, LS1016L	1
23	256633-1	PIN 6, LS1016L	1
24	231928-3	RING SPRING 8, LS1016L	1
25	961057-5	RETAINING RING S-17, LS1016L	1
26	211251-2	B.BEARING 6003LLB, 5477NB	1
27	285686-3	BEARING RETAINER 94, LS1214FL	1
28	240001-8	FAN 80, LS1016L	1
29	516736-6	ARMATURE ASS'Y 115V, LS1212	1
30	681642-5	INSULATION WASHER, LS1016L	1
31	211061-7	B. BEARING 6000LLB, 6222DWE	1
32	416264-0	BAFFLE PLATE, LS1212	1
33	664463-0	CORD (2X14X8 SJ), 5007F	1
34	682505-8	CORD GUARD, 5007F	1
35	687052-4	STRAIN RELIEF, 5007F	1
36	265995-6	TAPPING SCREW 4X18, BO4556K	2
37	414546-4	CAM, LS1011	1
38	416000-4	LOCK OFF LEVER, LS1040	1
39	411478-6	SWITCH BUTTON, LS1011	1
40	182910-4	HANDLE SET, LS1013	1
41	231457-6	COMP. SPRING 3, HR2400	1
42	651923-1	SWITCH, LS1040	1
43	415999-0	SWITCH LEVER, LS1040	1
44	265995-6	TAPPING SCREW 4X18, BO4556K	6
45	182910-4	HANDLE SET, LS1013	1
46	921467-8	HEX BOLT M8X45, LS1013	1
47	262003-4	RUBBER RING 6, LS1013	1
48	911323-0	P.H. SCREW M6X16, LS1211	1
49	421562-9	GRIP, LS1013	1
50	344420-1	GRIP HOLDER, LS1013	1
51	911323-0	P.H. SCREW M6X16, LS1211	1
52	188379-0	BLADE CASE SET, LS1214F	1
	183896-5	BLADE CASE, LS1214	
	153633-1	BLADE CASE CPLT., LS1212	
	151816-7	BLADE CASE COMPLETE, LS1212	
53	819215-6	MAKITA LOGO LABEL, LS1214L	1



Parts Breakdown

LS1212

	819064-1	MAKITA MARK, 5402NA	
54	344045-1	STOPPER ARM PLATE, LS1211	1
55	911113-1	P.H. SCREW M4X10, LS1016L	1
56	213460-9	O RING 35, LS1016L	1
57	419277-0	DUST NOZZLE, LS1016L	1
	416133-5	DUST NOZZLE, LS1013	
58	265717-4	SCREW M6X43, LS1016L	1
59	262001-8	RING 5, LS1016L	1
60	317176-9	STOPPER ARM, LS1212	1
61	211031-6	BALL BEARING 608LLB, 9227C	1
62	961054-1	RETAINING RING S-14, 6302	1
63	226750-1	SPIRAL BEVEL GEAR 35, LS1214FL	1
64	262074-1	RUBBER RING 20, LS1013	1
65	267035-6	F. WASHER 14, LS1214F	1
66	316473-0	HOUSING W/O BEARING, LS1211	1
67	254202-2	KEY 4, 9924DB	1
68	322989-5	SPINDLE, LS1212	1
69	211278-2	BALL BEARING 6203DDW, GA7021	1
70	285828-9	BEARING RETAINER 66, LS1211	1
71	257022-3	RING 16, LS1013	1
72	224333-1	FLANGE 53, LS1040	1
73	257060-5	RING 15.88,LS1013	1
74	224333-1	FLANGE 53, LS1040	1
75	265405-3	H.F.H. BOLT M10X20, LS1016L	1
76	344473-0	CENTER PLATE, LS1212	1
77	344038-8	CENTER COVER, LS1211	1
78	265324-3	H.F.H. BOLT M8X12, LS1016L	1
79	231613-8	T. SPRING 45, LS1211	1
80	450130-1	SAFETY COVER, LS1212	1
	416263-2	SAFETY COVER, LS1211	
81	253977-0	F. WASHER 6, LS1011	1
82	911213-7	P.H. SCREW M5X12, LS1040	1
83	265008-3	.SCREW M5, LS1011	1
	265985-9	HEX.SOCKET HEAD BOLT M6, LS1016L	
84	911223-4	P.H. SCREW M5X16, 5007MG	2
85	265406-1	H.BOLT M10X130, LS1211	1
86	253024-7	F. WASHER 10, LS1016L	1
87	331428-4	PIPE, 2414NB	1
88	252105-4	HEX LOCK NUT M8-13, LS1040	1
89	941201-0	F. WASHER 8, 5007NK	1
90	151813-3	ARM COMPLETE, LS1212	1
91	322988-7	STOPPER PIN, LS1220	1
92	213011-8	O RING 7, HR2511,LS1214FL	1
93	687095-6	STRAIN RELIEF, LS1016L	1
94	266026-4	TAPPING SCREW 4X12, LS1016L	1
95	252130-5	HEX LOCK NUT M10, LS1016L	1
96	253024-7	F. WASHER 10, LS1016L	1
97	265455-8	HEX BOLT M8X28, LS1212	2
99	216003-6	STEEL BALL 10, 2401B, LS1013	2
100	344475-6	GUIDE PLATE, LS1212	1
101	231631-6	TORSION SPRING 30, LS1212	1
102	413067-3	INDICATION PLATE, LS1013	2
103	911114-9	P.H. SCREW M4X10, LS1013FL	2
104	233168-9	COMPRESSION SPRING 5, LS1013	2
105	266131-7	HEX SOCKET HEAD BOLT M12X12, LS1013	2
106	253852-0	F. WASHER 8, LS1211	1
107	265442-7	HEX BOLT M8X40, LS1013	1
108	416886-6	KERF BOARD, LS1211,LS1212	2
109	266026-4	TAPPING SCREW 4X12, LS1016L	4
	251314-2	SCREW M4X12, LXPH03	
110	252014-7	HEX LOCK NUT M6-10, LS1040	1



Parts Breakdown

LS1212

111	344463-3	SUB FENCE PLATE, LS1013	1
112	150732-0	SUB FENCE CPLT., LS1212	1
	150796-4	SUB FENCE COMPLETE, LS1220	
113	253804-1	F. WASHER 6, LS1016L	1
114	912357-6	C.S.H. SCREW M6X35, LS1013	1
115	251887-5	SCREW M6X10, LS1016L	1
116	921451-3	HEX BOLT M8X30, LS1011	4
117	316905-7	GUIDE FENCE, LS1212	1
	317291-9	GUIDE FENCE, LS1212	
118	266132-5	SCREW M8X320, LS1013FL	1
119	931402-8	HEX NUT M8, 5037NB	1
120	271314-6	KNOB 40, LS1212	1
	273444-9	GRIP 37, LS1013	
121	331491-7	PIPE 9-200, LS1013FL	1
122	152541-3	KNOB 48 COMPLETE, LS1013	1
123	421563-7	CAP 10, LS1013	1
124	322924-3	COIL SPRING, LS1013FL	1
125	322938-2	LOCK PIN, LS1212	1
126	266034-5	TAPPING SCREW 4X16, LS1016L	1
127	232075-3	LEAF SPRING, LS1016L	1
128	961018-5	STOP RING E-5, LS1016L	1
129	231307-5	COMP. SPRING 6, LS1013	1
130	316882-3	PIN HOLDER, LS1212	1
131	344411-2	SLIDE STOPPER, LS1013	1
132	251267-5	P.H. SCREW M6, LS1016L	1
133	256196-7	PIN 5, LS1013	1
134	266034-5	TAPPING SCREW 4X16, LS1016L	1
135	344412-0	STOPPER HOLDER, LS1013	1
136	331493-3	TURN STOPPER, LS1013FL	1
137	266034-5	TAPPING SCREW 4X16, LS1016L	2
138	911113-1	P.H. SCREW M4X10, LS1016L	1
139	343678-9	INDICATION PLATE, LS1016L	1
140	151480-4	TURN BASE COMPLETE, LS1212	1
	151814-1	TURN BASE COMPLETE, LS1212	
141	921356-7	HEX BOLT M6X35, LS1013	2
142	152542-1	SQUARE ROD COMPLETE, LS1013	1
143	151477-3	ARM HODER CPLT., LS1212	1
	151815-9	ARM HOLDER COMPLETE, LS1212	
144	251662-9	H. BOLT M10X100, 2030N	1
145	911113-1	P.H. SCREW M4X10, LS1016L	1
146	416006-2	LEVER 100, LS1040	1
147	252144-4	HEX. NUT M10-17, LXSL01	1
148	253024-7	F. WASHER 10, LS1016L	1
149	152540-5	BEARING BOX B COMPLETE, LS1013FL	1
150	922451-6	H.S.H. BOLT M8X30, JS3200	2
151	266026-4	TAPPING SCREW 4X12, LS1016L	3
152	816325-0	MITER SCALE PLATE, LS1212	1
153	344474-8	SLIDE PLATE, LS1212	2
155	286212-1	CAP 20, 2705	4
156	150733-8	BASE CPLT., LS1212	1
	151812-5	BASE COMPLETE, LS1212	
157	253804-1	F. WASHER 6, LS1016L	1
158	911113-1	P.H. SCREW M4X10, LS1016L	1
159	941201-0	F. WASHER 8, 5007NK	1
160	231266-3	COMP. SPRING 5, LXSL01	1
	762001-3	TRIANGLE RULE, LS1016L	1
	782232-8	BOX WRENCH 13, LS1016	1
	782212-4	SOCKET WRENCH 13, LS1011	
	122523-9	DUST BAG, LS1040	1
	411478-6	SWITCH BUTTON, LS1011	2
	251887-5	SCREW M6X10, LS1016L	1



Parts Breakdown

LS1212

322983-7	VICE ROD, LS1013	1
271303-1	KNOB, LS1030-T2	1
122540-9	WISE ASS'Y, LS1212	1
253804-1	F. WASHER 6, LS1016L	1
343651-9	WISE PLATE, LS1016L	1
251370-2	PAN HEAD SCREW, 5007MG	1
A-91182	12 70T MAKBLADE,LS1220	1
251961-9	H.S.H. SCREW M6X10, LS1040	1