







Parts Breakdown

LS1214FL

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	265995-6	TAPPING SCREW 4X18, BO4556K	2
2	416075-3	REAR COVER, LS1013	1
3	265995-6	TAPPING SCREW 4X18, BO4556K	1
4	631237-4	CONTROLLER, LS1214FL	1
6	911373-5	P.H. SCREW M6X50, LS1013	4
7	154719-4	MOTOR HOUSING CPL., LS1013L	1
8	CB154	CARBON BRUSH SET, 194986-9	1
	194986-9	CARBON BRUSH SET, 194986-9	
	181047-4	CARBON BRUSH SET 154,5402A	
9	643650-4	BRUSH HOLDER CAP, 5007F	2
10	863031-8	NAME PLATE, LS1214FL	1
11	596156-0	FIELD ASS'Y 115V, LS1212	1
12	266059-9	T. SCREW, FLANGE 5X75,2414B	2
13	416264-0	BAFFLE PLATE, LS1212	1
14	211061-7	B. BEARING 6000LLB, 6222DWE	1
15	681642-5	INSULATION WASHER, LS1016L	1
16	516931-8	ARMATURE ASS'Y, LS1214L	1
17	240001-8	FAN 80, LS1016L	1
18	911223-4	P.H. SCREW M5X16, 5007MG	2
19	285686-3	BEARING RETAINER 94, LS1214FL	1
20	210301-0	BALL BEARING 6003DDW, RT0700C	1
	211275-8	BALL BEARING 6003DDW, 9741	
21	961057-5	RETAINING RING S-17, LS1016L	1
22	231928-3	RING SPRING 8, LS1016L	1
23	256633-1	PIN 6, LS1016L	1
24	231240-1	COMP. SPRING 7, LS1016L	1
25	961018-5	STOP RING E-5, LS1016L	1
26	253804-1	F. WASHER 6, LS1016L	1
27	257163-5	RING 6, LS1016L	1
28	345605-2	LINK PLATE, LS1214L	1
29	922331-6	H.S.H. BOLT M6X20, LS1016L	1
30	253804-1	F. WASHER 6, LS1016L	1
31	257163-5	RING 6, LS1016L	1
32	316470-6	SPRING HOLDER, LS1211	1
33	233454-8	COMPRESSION SPRING 34, LS1214L	1
46	153523-8	SWITCH BOX CPL.,LS1013FL	1
47	651522-9	SWITCH SLE6A, LS1013L	1
48	411478-6	SWITCH BUTTON, LS1011	1
49	183980-6	HANDLE SET, LS1013L	1
50	682505-8	CORD GUARD, 5007F	1
51	664463-0	CORD (2X14X8 SJ), 5007F	1
52	687052-4	STRAIN RELIEF, 5007F	1
53	265995-6	TAPPING SCREW 4X18, BO4556K	2
54	414546-4	CAM, LS1011	1
55	416000-4	LOCK OFF LEVER, LS1040	1
58	231457-6	COMP. SPRING 3, HR2400	1
60	631576-2	POWER SUPPLY CIRCUIT, LS1013L	1
61	651923-1	SWITCH, LS1040	1
63	415999-0	SWITCH LEVER, LS1040	1
64	265995-6	TAPPING SCREW 4X18, BO4556K	8
65	183980-6	HANDLE SET, LS1013L	1
66	921467-8	HEX BOLT M8X45, LS1013	1
67	262003-4	RUBBER RING 6, LS1013	1
68	911323-0	P.H. SCREW M6X16, LS1211	1
69	421562-9	GRIP, LS1013	1
70	344420-1	GRIP HOLDER, LS1013	1
71	911323-0	P.H. SCREW M6X16, LS1211	1
72	911114-9	P.H. SCREW M4X10, LS1013FL	1



Parts Breakdown

LS1214FL

73	419277-0	DUST NOZZLE, LS1016L	1
74	213460-9	O RING 35, LS1016L	1
75	911113-1	P.H. SCREW M4X10, LS1016L	1
76	265717-4	SCREW M6X43, LS1016L	1
77	262001-8	RING 5, LS1016L	1
78	317176-9	STOPPER ARM, LS1212	1
79	819215-6	MAKITA LOGO LABEL, LS1214L	1
80	344045-1	STOPPER ARM PLATE, LS1211	1
81	421952-6	CUSHION, LS1013L	1
82	211031-6	BALL BEARING 608LLB, 9227C	1
83	961054-1	RETAINING RING S-14, 6302	1
84	226750-1	SPIRAL BEVEL GEAR 35, LS1214FL	1
85	262074-1	RUBBER RING 20, LS1013	1
86	267035-6	F. WASHER 14, LS1214F	1
87	213675-8	O RING 54, LS1214	1
88	316473-0	HOUSING W/O BEARING, LS1211	1
89	254202-2	KEY 4, 9924DB	1
90	322989-5	SPINDLE, LS1212	1
91	211278-2	BALL BEARING 6203DDW, GA7021	1
92	285828-9	BEARING RETAINER 66, LS1211	1
93	257022-3	RING 16, LS1013	1
94	911223-4	P.H. SCREW M5X16, 5007MG	2
95	224333-1	FLANGE 53, LS1040	1
96	257060-5	RING 15.88,LS1013	1
97	224333-1	FLANGE 53, LS1040	1
98	265405-3	H.F.H. BOLT M10X20, LS1016L	1
99	344473-0	CENTER PLATE, LS1212	1
100	345603-6	CENTER COVER, LS1013L	1
101	265324-3	H.F.H. BOLT M8X12, LS1016L	1
102	265008-3	.SCREW M5, LS1011	1
103	231691-8	TORSION SPRING 45, LS1214L	1
104	419074-4	SAFETY COVER, LS1214L	1
105	253977-0	F. WASHER 6, LS1011	1
106	911218-7	P.H. SCREW M5X14, DA6300	1
107	421916-0	GUARD, LS1013L	1
108	345611-7	GUARD PLATE, LS1214L	1
109	188028-9	BLADE CASE SET, LS1214L	1
110	266026-4	TAPPING SCREW 4X12, LS1016L	1
111	419078-6	LEAD COVER HOLDER, LS1013L	1
112	419077-8	LEAD COVER, LS1214L	1
113	418104-8	LENS, LS1013L	1
114	804293-9	LASER LABEL, LS1013FL	1
115	266306-8	SHOULDER SCREW M5, LS1016L	1
116	266229-0	HEX.SCREW M5X8, 4200N	2
117	419379-2	BLOCK C, LS1013FL	1
118	266318-1	HEX. SOCKET SET SCREW M4X6, LS1016L	1
119	231664-1	TORSION SPRING 9, LA1013L	1
120	911003-8	P.H. SCREW M3X6, FD02W	1
121	419378-4	BLOCK B, LS1013FL	1
122	911003-8	P.H. SCREW M3X6, FD02W	1
123	231664-1	TORSION SPRING 9, LA1013L	1
124	266318-1	HEX. SOCKET SET SCREW M4X6, LS1016L	1
125	638442-4	LASER CIRCUIT CPL.,LS1013FL	1
126	419380-7	TOP COVER, LS1013FL	1
127	253807-5	F. WASHER 5, 6012HDW	1
128	265753-0	THUMB SCREW M5X24, LS1013L	1
129	266042-6	TAPPING SCREW BIND CT 4X20, LS1016L	2
130	331428-4	PIPE, 2414NB	1
131	252105-4	HEX LOCK NUT M8-13, LS1040	1
132	941201-0	F. WASHER 8, 5007NK	1
133	154780-1	ARM CPL., LS1214L	1



Parts Breakdown

LS1214FL

134	687095-6	STRAIN RELIEF, LS1016L	1
135	266026-4	TAPPING SCREW 4X12, LS1016L	1
136	322988-7	STOPPER PIN, LS1220	1
137	213011-8	O RING 7, HR2511,LS1214FL	1
139	251961-9	H.S.H. SCREW M6X10, LS1040	1
140	265371-4	HEX BOLT M8X30, LS1011	2
141	265412-6	HEX. BOLT M8X20, LS1013	2
142	216003-6	STEEL BALL 10, 2401B, LS1013	2
143	345418-1	GUIDE PLATE, LS1013	1
144	231626-9	TORSION SPRING 28, LS1013	1
145	413067-3	INDICATION PLATE, LS1013	2
146	911114-9	P.H. SCREW M4X10, LS1013FL	2
147	233168-9	COMPRESSION SPRING 5, LS1013	2
148	266131-7	HEX SOCKET HEAD BOLT M12X12, LS1013	2
149	151459-5	ARM HOLDER COMPLETE, LS1013	1
150	251662-9	H. BOLT M10X100, 2030N	1
151	911113-1	P.H. SCREW M4X10, LS1016L	1
152	416006-2	LEVER 100, LS1040	1
153	252144-4	HEX. NUT M10-17, LXSL01	1
154	253024-7	F. WASHER 10, LS1016L	1
155	231266-3	COMP. SPRING 5, LXSL01	1
156	152542-1	SQUARE ROD COMPLETE, LS1013	1
157	921356-7	HEX BOLT M6X35, LS1013	2
158	153832-5	TURN BASE CPLT., LS1013	1
159	152540-5	BEARING BOX B COMPLETE, LS1013FL	1
160	922451-6	H.S.H. BOLT M8X30, JS3200	2
161	253852-0	F. WASHER 8, LS1211	1
162	265442-7	HEX BOLT M8X40, LS1013	1
163	419222-5	KERF BOARD, LS1013L	2
164	266026-4	TAPPING SCREW 4X12, LS1016L	4
165	911108-4	P.H. SCREW M4X8, LS1013	1
166	252014-7	HEX LOCK NUT M6-10, LS1040	1
167	344463-3	SUB FENCE PLATE, LS1013	1
168	153892-7	SUB-FENCE CPL., LS1214	1
169	921451-3	HEX BOLT M8X30, LS1011	4
170	317757-9	GUIDE FENCE, LS1214	1
171	912357-6	C.S.H. SCREW M6X35, LS1013	1
172	253715-0	F. WASHER 6, NHP1310	1
173	251887-5	SCREW M6X10, LS1016L	1
174	266026-4	TAPPING SCREW 4X12, LS1016L	2
175	816326-8	MITER SCALE PLATE, LS1013	1
176	266132-5	SCREW M8X320, LS1013FL	1
177	931402-8	HEX NUT M8, 5037NB	1
178	271314-6	KNOB 40, LS1212	1
179	941201-0	F. WASHER 8, 5007NK	1
180	152541-3	KNOB 48 COMPLETE, LS1013	1
181	331491-7	PIPE 9-200, LS1013FL	1
182	421563-7	CAP 10, LS1013	1
183	322924-3	COIL SPRING, LS1013FL	1
184	322909-9	LOCK PIN, LS1013	1
185	253804-1	F. WASHER 6, LS1016L	1
186	231307-5	COMP. SPRING 6, LS1013	1
187	961018-5	STOP RING E-5, LS1016L	1
188	316899-6	PIN HOLDER, LS1013	1
189	266034-5	TAPPING SCREW 4X16, LS1016L	2
190	344411-2	SLIDE STOPPER, LS1013	1
191	251267-5	P.H. SCREW M6, LS1016L	1
192	256196-7	PIN 5, LS1013	1
193	331493-3	TURN STOPPER, LS1013FL	1
194	344412-0	STOPPER HOLDER, LS1013	1
195	266034-5	TAPPING SCREW 4X16, LS1016L	1



Parts Breakdown

LS1214FL

196	266026-4	TAPPING SCREW 4X12, LS1016L	1
197	816128-2	POINTER, LS1013	1
198	344477-2	SLIDE PLATE, LS1013	2
199	266034-5	TAPPING SCREW 4X16, LS1016L	1
200	232075-3	LEAF SPRING, LS1016L	1
201	251887-5	SCREW M6X10, LS1016L	2
202	153833-3	BASE CPL., LS1013	1
203	286212-1	CAP 20, 2705	4
210	941202-8	F. WASHER 8, BPB180	4
211	266048-4	T. SCREW 4X40, BO4556	2
212	125337-5	LIGHT ASS'Y, LS1013FL	1
213	233471-8	COMP. SPRING 6, LS1013FL	1
	122523-9	DUST BAG, LS1040	1
	122540-9	WISE ASS'Y, LS1212	1
	153898-5	SUB-FENCE R CPL., LS1214	1
	411478-6	SWITCH BUTTON, LS1011	2
	762001-3	TRIANGLE RULE, LS1016L	1
	783208-8	HEX WRENCH 2.5, LS1016L	1
	251887-5	SCREW M6X10, LS1016L	2
	322932-4	HOLDER 255, LS1013FL, LS1214FL	2
	A-94443	12X70T Q.MAKBLADE,LS1214F	1
	782232-8	BOX WRENCH 13, LS1016	1
	782212-4	SOCKET WRENCH 13, LS1011	
	810269-6	N/A	1