





Parts Breakdown

UM1000D

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	423121-5	SPONGE SEAL, UM104DWB	1
2	961018-5	STOP RING E-5, LS1016L	1
3	256686-0	PIN 7, UM103DST	1
4	251307-9	P.H. SCREW M4X15, UH3000D	1
5	125030-1	SHEAR BLADE ASSY, UM104DWB	1
6	216001-0	STEEL BALL 3.5, LXDT08	1
7	125030-1	SHEAR BLADE ASSY, UM104DWB	1
8	257116-4	RING 21, UM104DWB	1
9	221742-5	H. GEAR 52, UM104DWB	1
10	321835-9	SHAFT, UM104DWB	1
11	226804-4	GEAR 14-34, UM104DWB	1
12	321835-9	SHAFT, UM104DWB	1
13	629538-2	MOTOR, UH3000D	1
14	414168-0	SWITCH LEVER, UH3000D	1
15	414169-8	LOCK-OFF LEVER, 4390D	1
16	231390-2	COMP. SPRING 3, UH3000D	1
17	181834-1	HOUSING SET, UM1000D	1
18	342833-0	SET PLATE, 4071D	1
19	643909-9	BATTERY HOLDER, DA392D	1
20	651944-3	SWITCH DMC-1115-13, BCL180ZW	1
	651866-7	SWITCH,5090D	
21	181834-1	HOUSING SET, UM1000D	1
22	911143-2	P.H. SCREW M4X22, 6211D	5
23	855254-2	NAME PLATE, UM1000D	1
	B7000	BATTERY 7000 7.2V CLAMSHELL	1
	632002-4	BATTERY 7000, 6019DWE	
	191679-9	BATTERY 7000	
	410540-4	BLADE COVER, UM104DWB	1
	414938-7	BATTERY COVER, 6222DWE	1